




1989 BRONCO/ F150-F350/ F-SUPER DUTY



Electrical & Vacuum Trouble- Shooting Manual



ELECTRICAL AND VACUUM TROUBLESHOOTING MANUAL

FPS — 12129 - 89

ORDER INFORMATION

Information on how to order additional copies of this publication or other Ford publications, may be obtained by writing to Helm Incorporated at the address shown below. Other publications available include:

- Shop Manuals
- Service Specification Books
- Car/Truck Wiring Diagram Books
- Engine/Emissions Diagnosis Manuals

**Helm Incorporated
P.O. Box 07150
Detroit, Michigan 48207**

TABLE OF CONTENTS

How to Use This Manual	1
How to Find the Electrical Problem	2,3
Symbols (Electrical)	4
(Vacuum)	119
How to Find the Vacuum Problem	121
Component Testing	
Introduction	141
Main Light Switch	141
Hazard Switch	143
Ignition Switch	142
Turn Signal Switch	143
Windshield Wiper/Washer Switch	144
Interval Wiper/Washer Switch	145
A/C-Heater Function Selector	146
A/C-Heater Blower Switch	147
Location Index	148

SYSTEM INDEX

A/C-Heater	129
Anti-Lock Brakes	80
Brake Warning Indicator	74
Charge (Gasoline)	18
(Diesel)	23
Cigar Lighter	95
Coolant Temperature Gauge	88
Diesel Glow Plug Control	33
Electric Fuel Pump Control	92
Electronic Engine Control	37
Electronic Shift—4 Wheel Drive	82
E40D Transmission	44,47
Four-Wheel Drive Indicator	83
Fuel Injector Cooling Fan—(4.9L Only)	52
Fuel Tank Selector/Gauges (Diesel)	89
(Gasoline)	86
Fuse Panel (Diesel)	24
(Gasoline)	19

Gauges (Diesel)	89
(Gasoline)	86
Grounds	5
Heater	126
Horn	95
Ignition	27
Instrument Illumination	72
Lamps On Warning	68
Lamps	
Backup	66
Body Marker	58
Cargo	68
Dome	68
Exterior	56
Hazard	62
Headlamps	54
Instrument Illumination	72
License	57
Map	68
Marker	57
Park	57
Radio Illumination	72
Stop	62
Tail (Rear Park)	56
Trailer	58
Turn	62
Main Light Switch	18
Power Distribution (Diesel)	22
(Gasoline)	17
Power Door Locks	110
Power Windows	103
Radio (Stereo) (Electronic)	113
Rear Window Defrost	106
Seatbelt Warning	74
Speed Control	122
Start (Diesel)	32
(Gasoline)	27

Tacnometer	88
Tailgate Power Window	106
Trailer	117
Vacuum Distribution	120
Warning Indicators (Diesel)	77
(Gasoline)	74
Windshield Wiper/Washer	98
Windshield Wiper/Washer (Interval)	100

IMPORTANT SAFETY NOTICE

Appropriate service methods and proper repair procedures are essential for the safe, reliable operation of all motor vehicles, as well as the personal safety of the individual doing the work. This Manual provides general directions for accomplishing service and repair work with tested, effective techniques. Following them will help assure reliability.

There are numerous variations in procedures, techniques, tools, and parts for servicing vehicles, as well as in the skill of the individual doing the work. This Manual cannot possibly anticipate all such variations and provide advice or cautions as to each. Accordingly, anyone who departs from the instructions provided in this Manual must first establish that he compromises neither his personal safety nor the vehicle integrity by his choice of methods, tools or parts.

This manual contains the following diagnostic information:

- Electrical and Vacuum Schematics
- Component Location Indexes and Views
- Troubleshooting Hints
- Descriptions of Circuit Operation
- Component Testing

The vehicle's entire electrical system is broken down into individual systems. There are also sections for the vehicle's ground and power distribution circuitry. Each system section begins with a wiring schematic. The **Schematics** should always be your starting point in using this manual. These schematics show the paths of electrical current during proper circuit operation. The source of voltage (circuit breaker or fuse) is shown at the top of the page. All wire, connectors, splices, switches, and motors are shown in the flow of current to ground at the bottom of the page. Connector end views of switches and other components are shown to help with bench testing. Each circuit component is named (underlined titles). Wire and connector colors are listed (standard Ford color abbreviations are used). These abbreviations are:

COLOR ABBREVIATIONS

BL	Blue	N	Natural
BK	Black	O	Orange
BR	Brown	PK	Pink
DB	Dark Blue	R	Red
DG	Dark Green	P	Purple
GR	Green	T	Tan
GY	Gray	W	White
LB	Light Blue	Y	Yellow
LG	Light Green		


Where two colors are shown for a wire, the first color is the basic color of the wire. The second color is the stripe marking.

The **Component Location** section of each system helps you locate the circuit's components in the vehicle. A brief statement of the location is given as well as a reference to an il-

lustrative figure in the manual. There is also a full listing of connector, ground, diode, and splice locations in the **Location Index** in the back of the manual.

Resistors and diodes are currently covered with pvc molds and are taped to the harness outside of the tubing. Many of the 1989 model year assemblies will be covered with heat shrinkable tubing making the assembly small enough to be placed within the harness bundle. The wiring diagrams show the number of times the resistor and diodes are used as well as the distance from connector/length of wire in exact centimeters. Resistor and diodes are identified on the wiring diagrams by the following base part numbers:

Resistor/diode assembly	14A601
Diode only	14A604



OTHER ABBREVIATIONS

T/O (Tape Out) The point at which a harness branches to feed a component.

The **Troubleshooting Hints** offer shortcuts or tests in a three-column format that help you determine the cause of an electrical problem. They are not intended to be a rigid procedure for solving an electrical situation. Rather, Troubleshooting Hints represent a common-sense approach that is based on an understanding of the circuit.

A description of **How the Circuit Works** is written to help you understand the operation of the circuit as a whole. Emphasis is placed on how the components and circuitry interact in a properly working system.

A **Component Testing** section provides procedures to determine whether a component is

good or bad.

Notes, Cautions, and Warnings appear in boxes on text pages and contain important vehicle and mechanic **safety information**.

Notes give added information to help complete a particular procedure. Cautions are included to prevent making an error that could damage the vehicle. Warnings highlight areas where carelessness can cause personal injury. The following list contains some general **Warnings** that should be followed when working on a vehicle.

- Always wear safety glasses for eye protection.
- Use safety stands whenever a procedure requires being under a vehicle.
- Be sure that the **Ignition Switch** is always in the OFF position, unless otherwise required by the procedure.
- Set the parking brake when working on any vehicle. An automatic transmission should be in PARK. A manual transmission should be in NEUTRAL.
- Operate the engine only in a well-ventilated area to avoid the danger of carbon monoxide.
- Keep away from moving parts when the engine is running, especially the fan and belts.
- To prevent serious burns, avoid contact with hot metal parts such as the radiator, exhaust manifold, tail pipe, catalytic converter, and muffler.
- Do not allow flame or sparks near the battery. Gases are always present in and around the battery cell. An explosion could occur.
- Do not smoke.
- To avoid injury, always remove rings, watches, loose hanging jewelry, and loose clothing.

2 HOW TO FIND THE ELECTRICAL PROBLEM

TROUBLESHOOTING STEPS

These six steps present an orderly method of troubleshooting:

Step 1. Verify the problem.

- Operate the complete system and see all symptoms for yourself in order to:
 - check the accuracy and completeness of the customer's complaint.
 - learn more that might give a clue to the nature and location of the problem.

Step 2. Narrow the problem.

- Using this manual, narrow down the possible causes and locations of the problem in order to more quickly find the exact cause.
- Read the description of *How the Circuit Works* and study the wiring diagram. You should then know enough about the circuit operation to figure out where to check for this trouble.

Step 3. Test the cause.

- Use electrical test procedures to find the specific cause of the symptoms.
- *Troubleshooting Hints* will give some helpful ideas.
- The *Component Location* charts and the pictures will help you find components, grounds, and connectors.

Step 4. Verify the cause.

- Confirm the fact that you have found the correct cause through operating the parts of the circuit you think are good.

Step 5. Make the repair.

- Repair or replace the faulty component.

Step 6. Verify the repair.

- Operate the system as in Step 1 and check that your repair has removed all symptoms, and also has not caused any new symptoms.

Some engine circuits may need special test equipment and special procedures. See the


Shop Manual and other service books for details. You will find the circuits in this manual to be helpful with these special tests.

TROUBLESHOOTING TOOLS

JUMPER WIRE

This is a test lead used to connect two points of a circuit. A **Jumper Wire** can complete a circuit by bypassing an open.

Uses: Bypassing Switches or Open Circuits



VOLTMETER

A DC **Voltmeter** measures circuit voltage. Connect negative (- or black) lead to ground, and positive (+ or red) lead to voltage measuring point.

OHMMETER




Figure 1— Resistance Check

An **Ohmmeter** shows the resistance between two connected points (Figure 1).

TEST LIGHT




Figure 2— Test Light

A **Test Light** is a 12-volt bulb with two test leads (Figure 2).

Uses: Voltage Check. Short Check

SELF-POWERED TEST LIGHT





Figure 3— Continuity Check

The **Self-Powered Test Light** is a bulb, battery and set of test leads wired in series (Figure 3). When connected to two points of a continuous circuit, the bulb glows.

Uses: Continuity Check. Ground Check



TROUBLESHOOTING CHECKS

SWITCH CIRCUIT CHECK




Figure 4—Switch Circuit Check and Voltage Check

In a bad circuit with a switch in series with the load, jumper the terminals of the switch to power the load. If jumping the terminals powers the circuit, the switch is bad (Figure 4).

CONTINUITY CHECK (Locating open circuits)

With power off, connect one lead of **Self-Powered Test Light** or **Ohmmeter** to each end of circuit (Figure 3). Light will glow if circuit is closed. Switches and fuses can be checked in the same way.

VOLTAGE CHECK

Connect one lead of **Test Light** to a known good ground or the negative (-) battery terminal. Test for voltage by touching the other lead to the test point. Bulb goes on when the test point has voltage (Figure 4).

SHORT CHECK (short to ground)




Figure 5—Short Check

A fuse that repeatedly blows is usually caused by a short to ground. It's important to be able to locate such a short quickly (Figure 5).

- 1) Turn off everything powered through the fuse.
- 2) Disconnect other loads powered through the fuse:
 - Motors: disconnect motor connector.
 - Lights: remove bulbs.
- 3) Turn **Ignition Switch** to RUN (if necessary) to power fuse.
- 4) Connect one **Test Light** lead to hot end of blown fuse. Connect other lead to ground. Bulb should glow showing power to fuse. *(This step is just a check to be sure you have power to the circuit.)*
- 5) Disconnect the **Test Light** lead from ground and reconnect it to the load side of the fuse.
 - If the **Test Light** is off, the short is in the disconnected equipment.
 - If the **Test Light** goes on, the short is in the wiring. You must find the short by disconnecting the circuit connectors one at a time until the **Test Light** goes out. For example: with a ground at X, the bulb goes out when C1 or C2 is disconnected, but stays on after disconnecting C3. This

means the ground is between C2 and C3.

"GOOD GROUND" CHECK




Figure 6 — Grounds Checks

Turn on power to circuit. Perform Voltage Check between suspected bad ground and frame. Any voltage means ground is bad.






Turn off power to circuit. Connect one lead of **Self-Powered Test Light** or **Ohmmeter** to wire in question, and the other to known ground. If bulb glows, circuit ground is OK (Figure 6).

TROUBLESHOOTING HINTS









The circuit schematics in this manual are designed to make it easy to identify common points in circuits. This knowledge can help narrow the problem to a specific area. For example, if several circuits fail at the same time, check for a common power or ground connection. (See *Power Distribution* or *Grounds*). If part of a circuit fails, check the connections between the part that works and the part that doesn't work.

For example, if low beam headlights work but high beams and the indicator light don't work, then power and ground paths must be good. Since the dimmer switch is the component which switches this power to the high beam lights and indicator, it is most likely the cause of failure.




4 ELECTRICAL SYMBOLS




WIRE COLORS ARE LABELED FOR MATING HARNESS CONNECTOR




SEE GROUNDS PAGE 5-15




INSTRUMENT PANEL GROUND




6 GROUNDS (G801, 802)










8 GROUNDS (G801, G802, G805) (7.3L DIESEL WITH E40D TRANS.)






GROUNDS (FUEL TANKS AND REAR LAMPS) 9




10 GROUNDS (REAR LAMPS)






12 GROUNDS (G203)



DIESEL WITH MANUAL TRANS.



HOW THE CIRCUIT WORKS

The ground circuits shown here are complete and connect several components together to screw terminal ground points. On other pages only parts of these circuits may be shown. Partial ground circuits are shown dashed on those pages.

All simple or component ground circuits are shown on the individual circuit pages and are complete on those pages.

All ground wires are **57 BK** unless otherwise noted.

COMPONENT LOCATION

	Page- Figure
A/C Clutch Field Coil	Part of compressor
Anti-Lock Brake Module . .	Behind I/P left of center
Blower Resistors	Mounted to plenum next to blower 131-1
Brake Sensor	Part of master cylinder
Cooling Fan Motor	RH fender apron
Diesel/Warning Lamp Module	Behind LH side of I/P near fuse panel
Electronic Engine Control (EEC) Module	Behind LH kick panel
EEC Power Relay	Under plastic shield at the air cleaner support bracket
Rear Anti-lock Brake Proportioning Valve	Inside of LH frame rail behind #1 cross- member
Electronic Shift 4 Wheel Drive Control Module . .	RH cowl panel
Fuel Tank Selector Valve . .	On LH side frame member behind cab 91-1
Heater Blower Switch	At center of I/P
Refer to Component Testing	Page 000 for additional testing details.
HEGO Sensor	In communicator tube connecting both exhaust pipes 134-2,135-3
Inferred Mileage Sensor . .	Attached to instrument panel to left of steering column
Inline Fuel Pump	Inboard side of LH frame rail
Low Vacuum Warning Switch	7.3L RH fender apron
Power Window Master Switch	In LH door
Rear Defrost Control	Under LH corner of I/P
Seatbelt Warning Buzzer/Chime	Attached to rear RH side of I/P
Electronic Shift 4-Wheel Drive Switch	On LH side of I/P
Speed Sensor	At transmission
Tailgate Power Window Motor	In center of tailgate 109-3
Washer Pump	In washer reservoir
Windshield Wiper Motor . .	Attached to center of dash panel

Refer to the **Location Index** in the back of the manual for connector, ground, diode and splice descriptions and locations.

14 FUSE PANEL/CIRCUIT PROTECTION

REPLACEMENT OF FUSES/ CIRCUIT BREAKERS




GOOD FUSE




BLOWN FUSE

Fuses are mounted either in the **Fuse Panel** or in-line. They are identified by the numbered value in amperes, and by a color code. Some positions may have either a fuse with adapter or a circuit breaker. Be sure to replace a fuse or circuit breaker with the same kind of unit and with the same ampere rating. Remove fuses in order to check them.

CIRCUIT BREAKER OPERATION



Cycling Fuse Panel Type



Non-Cycling Fuse Panel Type




Cycling In-Line Type

Some circuits are protected by circuit breakers. (Abbreviated "c.b." in fuse chart.) They can be **Fuse Panel** mounted or in-line. Like fuses, they are rated in amperes.

Each circuit breaker conducts current through an arm made of two types of metal fastened together (bimetal arm). If the arm starts to carry too much current, it heats up. As one metal expands faster than the other the arm bends, opening the contacts. Current flow is broken. In the cycling type, the arm cools and straightens out. This closes the circuit again. This cycle repeats as long as the overcurrent exists, with power applied.

In the non-cycling type, there is also a coil wrapped around the bimetal arm. When an overcurrent exists and the contacts open, a small current passes through the coil. This current through the coil is not large enough to operate a load, but it does heat up both the coil and bimetal arm. This keeps the arm in the open position until power is removed.

FUSE LINKS




The fuse link is a short length of wire smaller in gauge than the wire in the protected circuit. The wire is covered with a thick non-flammable insulation. An overload causes the link to heat and the insulation to blister. If the overload remains, the link will melt, causing an open circuit. The links are color coded for wire size as follows:

COLOR CODE


BLUE	20 GA
BROWN	18 GA
BLACK	16 GA
GREEN	14 GA

When replacing, make tight crimp joints or hot solder joints for good connections.

DIODES



Diodes are electrical devices that permit current to flow in one direction only. The current flows in the direction indicated by the arrow.



Fuse Position	Amps	Circuits Protection
1	15	Stop/Hazard Lamps; Speed Control
2	—	(Not used)
3	—	(Not used)
4	15	Exterior Lamps; Instrument Illumination; Glove Compartment Lamp;
5	15	Map Lamp; Turn Lamps; Backup Lamps; Rear Window Defrost; E40D Transmission
6	15	Speed Control; Electronic Shift-4 Wheel Drive; Cargo Lamp (Bronco)
7	—	(Not Used)
8	15	Courtesy, Dome, Cargo Lamp (F-Series); Warning Buzzer
9	30	Heater; A/C-Heater
10	5	Instrument Illumination; Clock Dimming
11	15	Radio; Main Light Switch; Clock Illumination
12	25	Tailgate Power Window; Power Mirrors
13	30 c.b.	Power Door Locks; Electronic Shift-4 Wheel Drive
14	—	(Not used)
15	25	Tailgate Power Window
16	30 c.b.	Power Windows
17	10	Auxiliary Fuel Tank Selector
18	30	Horn; Cigar Lighter; Speed Control; 4.9L EFI After Run Blower
19	20	Anti-lock Brakes
20	15	Seatbelt Buzzer; Warning Indicators; Diesel Glow Plug Control; Diesel Indicators; Tachometer

Figure 1 - Fuse Panel

Fuse Value Amps	Color Code
4	Pink
5	Tan
10	Red
15	Light Blue
20	Yellow
25	Natural
30	Light Green

Power Distribution

The **Alternator** and **Battery** are connected together at the **Starter Relay** hot terminal. Other circuits originate at the **Starter Relay** hot terminal and are protected by fuse links. Low power circuits are also protected by fuses.

The **Ignition Switch** and **Main Light Switch** are powered at all times as are **Fuses 1, 4, 8, 12, and 16**. The other fuses are powered through the **Ignition Switch** or the **Main Light Switch**.






Figure 1 - Fuse Panel


CHARGE/POWER DISTRIBUTION (GASOLINE) 17



18 CHARGE/POWER DISTRIBUTION (GASOLINE)



CHARGE/POWER DISTRIBUTION (GASOLINE) 19



HOW THE CIRCUIT WORKS

The **Battery**, **Alternator** and **Voltage Regulator** make up the **Charging System**. With the **Ignition Switch** in **RUN**, **Battery** voltage is applied through the solid-state electronic control of the **Voltage Regulator**. The electronic control applies **Battery** voltage to the **Alternator** field.

With current in the field and the rotor turning, the **Alternator** stator produces a DC voltage at B+ terminals (to **Battery**). If the **Alternator** output voltage is greater than the **Battery** terminal voltage, current will flow from the **Alternator** to the **Battery**, as well as to the vehicle electrical load.

If the **Alternator** voltage is less than the **Battery** terminal voltage, current will flow from the **Battery** to supplement the alternator output in supplying the vehicle electrical load.

COMPONENT LOCATION

Page-
Figure

Fuse Links A,F,G,J,L,P, M, N, Y, W	Near starter relay	—
Radio Noise Capacitor ...	Attached to voltage regulator	—
Starter Relay	On RH fender apron	—

Refer to the **Location Index** in the back of the manual for connector, ground, diode and splice descriptions and locations.

Refer to section 31-01 of the shop manual.

TROUBLESHOOTING HINTS

CONDITION	POSSIBLE CAUSE	ACTION
<ul style="list-style-type: none"> • Improper Charging 	<ul style="list-style-type: none"> • Loose/worn alternator belt • Defective/dead battery • Fuse Link J open at starter relay • Poor connection between battery terminals and cable clamps/ damaged cables 	<ul style="list-style-type: none"> • Tighten/replace • Replace battery • Visually check for open in link, replace • Clean, tighten and/or replace
<ul style="list-style-type: none"> • Alternator Warning Indicator remains on after initial start up 	<ul style="list-style-type: none"> • Poor connection on Alternator, Regulator, Starter Relay and/or Alternator Output Control Relay 	<ul style="list-style-type: none"> • Make sure connections are clean and tight and refer to shop manual section 31-01, Charging System Diagnosis




Figure 1 — Lower RH Side of Engine (5.0L, 5.8L, 7.5L, 8 Cyl.)







Figure 2 — Lower RH Side of Engine (4.9L 6 Cyl. ONLY)





CONTINUED
ON PAGE 24

24 CHARGE/POWER DISTRIBUTION (DIESEL)



HOW THE CIRCUIT WORKS

The **Batteries, Alternator and Voltage Regulator** make up the **Diesel Charging System**.

With the **Ignition Switch** in **RUN**, **Battery** current flows through the solid-state **Electronic Control of the Voltage Regulator**. The **Electronic Control** applies **Battery** voltage to the **Alternator** field.

With current in the field and the rotor turning, the **Alternator** stator produces a DC voltage at **B+** terminals (to **Battery**).

If the alternator output voltage is greater than the battery voltage, current will flow from the alternator to the **Battery** as well as to the vehicle electrical load.

If the alternator voltage is less than the battery voltage, current will flow from the battery to help supply the vehicle load.

TROUBLESHOOTING HINTS

CONDITION	POSSIBLE CAUSE	ACTION
<ul style="list-style-type: none"> • Improper Charging 	<ul style="list-style-type: none"> • Loose/worn alternator belt • Defective/dead battery • Fuse Link J open at starter relay • Poor connection between battery terminals and cable clamps/ damaged cables 	<ul style="list-style-type: none"> • Tighten/replace • Replace battery • Visually check for open in link, replace • Clean, tighten and/or replace
<ul style="list-style-type: none"> • Alternator Warning Indicator remains on after initial start up 	<ul style="list-style-type: none"> • Poor connection on Alternator, Regulator, Starter Relay and/or Alternator Output Control Relay 	<ul style="list-style-type: none"> • Make sure connections are clean and tight and refer to shop manual section 31-01, Charging System Diagnosis

COMPONENT LOCATION

Charge Indicator	In instrument cluster	Page- Figure
Fuse Links B, C, F, G, J, L, M, W	Near starter relay	—
Fuse Links U, V	RH fender apron	—
Radio Noise Capacitor ...	Near voltage regulator	—
Starter Relay	RH inner fender	—

Refer to the **Location Index** in the back of the manual for connector, ground, diode and splice descriptions and locations.

Refer to section 31-01 of the shop manual.




Figure 1 - Battery Wiring LH Side (Diesel Engine)





Figure 2 - Starter Wiring (Diesel Engine)


28 START/IGNITION (5.0L, 5.8L, 7.5L)

SEE CHARGE/
POWER DISTRIBUTION
PAGE 17




WITH MANUAL TRANSMISSION

FROM START/IGNITION AND
START/GLOW PLUG CONTROL
PAGE 27 (START/IGNITION)
33 START/GLOW PLUG CONTROL)



WITH AUTOMATIC TRANSMISSION

FROM START/IGNITION AND
START/GLOW PLUG CONTROL
PAGE 27 (START/IGNITION)
33 (START/GLOW PLUG CONTROL)



HOW THE CIRCUIT WORKS

START

The **Battery, Starter Motor, Starter Relay, and Ignition Switch** make up the **Starting System**. In vehicles with automatic transmissions, the **Neutral Safety Start Switch** must be closed (**Park** or **Neutral**) in order to operate the **Starter Motor**. In vehicles with manual transmissions, the **Clutch Interlock Switch** must be closed in order to operate the **Starter Motor**.

Turning the **Ignition Switch** to **START** sends battery voltage to the **Starter Relay** coil and energizes the relay. Voltage from the **Battery** is then applied directly through the **Starter Relay** to the **Starter Motor** to start the engine.

When the **Ignition Switch** is in **START**, battery voltage is applied to both the **START** (circuit 32) and **RUN** (circuit 20) terminals of the **Thick Film Integrated Ignition (TFI) Module**. When the **Ignition Switch** is in the **RUN** position, the voltage on circuit 32 drops to zero.

COMPONENT LOCATION

	Page-Figure
Charge Indicator	Part of instrument cluster —
Clutch Interlock Switch ...	Near top of clutch pedal 31-1
Fuse Link M	At starter relay —
Fuse Link D	At C110 LH engine compartment —
Ignition Coil	On engine 133-1, 136-4
Ignition Module	At distributor 133-1
Manual Lever Position Sensor	Part of E40D transmission 51-1
Neutral Safety Switch	Part of automatic transmission —
Radio Noise Capacitor ...	At ignition coil —
Starter Relay	RH inner fender —

Refer to the **Location Index** in the back of the manual for connector, ground, diode and splice descriptions and locations.

TROUBLESHOOTING HINTS

CONDITION	POSSIBLE CAUSE	ACTION
• Starter does not operate	• No voltage at starter Relay/Starter	• Check for open at Fuse Link M
• Starter cranks slowly/solenoid clicks	• Low charged battery/defective starter	• Check for clean tight connection at battery/worn battery or repair/replace starter
• Poor engine performance	• Engine operating with a fixed 10° BTDC spark timing and the EGR system is not operating	• System operating in "fail mode" *see EEC system note

***NOTE:** Because of the complexity of the EEC system, special test equipment is required to diagnose it. Refer to the **ENGINE/EMISSIONS DIAGNOSIS MANUAL, VOLUME H** for diagnostic procedures.

HOW THE CIRCUIT WORKS

IGNITION

The **EEC Distributor** does not have a magnetic pickup or spark advance. Instead all ignition timing is controlled by the **Electronic Engine Control (EEC) Module**. Refer to the Engine/Emissions Diagnosis Manual Volume H for complete details.

The **EEC IV Ignition System** includes a **Thick Film Integrated Ignition (TFI) Module**, which is mounted on the side of the **Distributor**.

- The pickup in the **Distributor** provides a signal input to the **EEC Module**. On the 4.9L, 5.0L and 5.8L this signal is provided through the **TFI Module**. On the 7.5L the signal is padded directly from the pickup to the **EEC Module**.

When the engine is running:

- The **EEC Module** then sends a signal to the **TFI Module** which switches current on and off in the primary circuit of the ignition coil according to the **EEC Module** signal.
- Each interruption of primary current makes the **Ignition Coil** secondary produce an open circuit high-voltage pulse of up to 40,000 volts.
- High voltage pulses are transmitted to the **Distributor**, which sends them to fire the spark plugs.

Two signal circuits (324 and 349) are connected between the **TFI Ignition Module** and the **Electronic Engine Control (EEC) Module**.

Refer to Engine/Emissions Diagnosis Manual, Volume H.






Figure 1 — Clutch Interlock Switch

32 START/GLOW PLUG CONTROL/RUN (DIESEL)



SEE GROUNDS
PAGE 12



34 START/GLOW PLUG CONTROL/RUN (DIESEL)

HOW THE CIRCUIT WORKS

The Diesel Start/Glow Plug Control circuit applies power to the **Glow Plugs** which heat the combustion chambers, so that the cold diesel engine can be started.

Glow Plug Control

The solid state **Glow Plug Controller** is attached to the top of the engine block. It maintains glow plug pre-glow and after-glow time. The **Glow Plug Controller** controls the circuit's operation by sensing engine temperature, glow plug voltage, and after-glow voltage from start/run circuit.

When the **Ignition Switch** is turned to RUN, voltage from **Fuse Link V** is applied through the **Glow Plug Controller** to the **Glow Plugs Wait to Start Indicator Lamp**.

The glow plugs are heated from zero to fifteen seconds, depending on engine coolant temperature. After this time, the controller cycling switch opens and turns OFF the **Glow Plugs Wait to Start Indicator Lamp**.

The **Glow Plugs** are now warm enough for the engine to be started.

At the same time the **Ignition Switch** is turned to Run, voltage from **Fuse Link V** is applied to the After-Glow Timer (located inside the Glow Plug Controller). The After-Glow Timer cycles the **Glow Plugs** for up to two minutes, depending on engine temperature. The After-Glow Timer then opens. The **Wait to Start Indicator Lamp** will not light during After-Glow period.

If the ignition switch is turned OFF, it can be turned ON immediately and the **Glow Plug** heating cycle will start again.

Diesel Start/Run

The diesel engine uses two batteries to provide extra power for starting and glow plug

COMPONENT LOCATION

		Page-Figure
Cold Advance Solenoid ..	In injection pump	—
Cold Idle Solenoid	On injection pump	—
Engine Temperature Switch	At left front end of engine	—
Fuel Heater	RH side of engine	—
Fuel Shut-Off Solenoid ...	In injection pump	—
Fuse Link B, C, M	Near starter relay	—
Fuse Link U, V	RH fender apron	—
Glow Plug Controller	LH rear top of engine	35-1
Glow Plug Indicator	In diesel warning lamp module	—
Starter Relay	RH fender	—

Refer to the **Location Index** in the back of the manual for connector, ground, diode and splice descriptions and locations.

heating. Power is applied from the batteries through heavy gauge wires to the Starter Solenoid in the Starter motor assembly. When the **Glow Plug Indicator** goes out, the **Ignition Switch** can be turned to START. With the transmission selector in park or neutral (automatic transmission), or the clutch pedal depressed (manual transmission), power is applied to the **Starter Relay**. The relay applies power to the solenoid coil which closes contacts to apply battery power to the starter motor.

With the **Ignition Switch** in Start or Run, voltage is supplied to the **Fuel Line Heater, Fuel Shut-Off Solenoid, and the Engine Temperature Switch** through **Fuse Links U and V**.

The **Fuel Heater/Water Separator** heats the diesel fuel to melt any wax which might clog filter.

The **Fuel Shut-Off Solenoid** controls the flow of fuel into the Injection Pump. With the **Ignition Switch** in Start or Run, the solenoid is energized, and fuel is allowed to flow into the Injection Pump. When the **Ignition Switch** is

turned to Off, the solenoid is de-energized, fuel flow stops, and the engine stops running.

The **Engine Temperature Switch** provides voltage to the **Cold Advance Solenoid** and the **Cold Idle Solenoid**. When engine temperature is below 62°C (112°F) the **Engine Temperature Switch** is closed. When the **Ignition Switch** is turned to Start or Run, the Solenoids are energized, advancing Injection Pump timing and Engine Idle, allowing the engine to run more smoothly when cold. When the engine temperature reaches 62°C (112°F), the **Engine Temperature Switch** opens. This de-energizes the Solenoids, returning the Timing and Idle to normal.

Refer to **Engine/Emissions Diagnosis Manual, volume H** for additional diagnosis information.

TROUBLESHOOTING HINTS

CONDITION	POSSIBLE CAUSE	ACTION
<ul style="list-style-type: none"> No Glow Plugs operate 	<ul style="list-style-type: none"> No voltage at Y wire connector of Glow Plug Controller 	<ul style="list-style-type: none"> Check Fuse Links B and C and check wiring
<ul style="list-style-type: none"> One Glow Plug does not operate 	<ul style="list-style-type: none"> No voltage at BR wire of Glow Plug 	<ul style="list-style-type: none"> Check for open in BR wire









Figure 1 — Glow Plug Controller


36 ELECTRONIC ENGINE CONTROL (EFI) (4.9L ONLY)







38 ELECTRONIC ENGINE CONTROL (EFI) (4.9L ONLY)










42 ELECTRONIC ENGINE CONTROL (EFI 5.0L, 5.8L, 7.5L)






44 ELECTRONIC ENGINE CONTROL (EFI 5.0L, 5.8L, 7.5L)





ELECTRONIC ENGINE CONTROL (DIESEL WITH E40D) 47



HOW THE CIRCUIT WORKS

Gasoline Engine

The **Electronic Engine Control-IV System (EEC-IV)** is a controlling system designed to optimize tailpipe emissions, fuel economy, driveability, and performance. This is accomplished by means of an on-board **Electronic Engine Control (EEC) Module**, which receives input from various sensors. The **EEC Module** makes computations based on these inputs, then sends controlling signals to various components to achieve desired air/fuel ratio, ignition timing, EGR flow, **Thermactor** air flow and idle speed.

Diesel Engine with E4OD Transmission

The **Electronic Engine Control-IV System (EEC-IV)** is employed on the 7.3L diesel engine only to operate the **E4OD Automatic Transmission**. This transmission requires the **Electronic Engine Control (EEC) Module** to provide electronic control of the locking converter clutch and shift/kickdown controls.

System Inputs

The **Profile Ignition Pick-Up (PIP) Sensor** supplies crankshaft position and frequency information to the **EEC Module** (from the distributor).

The **Throttle Position Sensor (TPS)** provides the **EEC Module** with a signal proportional to the angle of the throttle plate.

The **Engine Coolant Temperature (ECT) Sensor** monitors the temperature of the engine coolant and provides a corresponding signal to the **EEC Module**.

The **Heated Exhaust Gas Oxygen (HEGO) Sensor** sends a voltage signal to the **EEC Module** which indicates the oxygen level in the exhaust gases.

The **Manifold Absolute Pressure (MAP) Sensor** measures the pressure in the intake manifold and provides this information as a variable fre-

COMPONENT LOCATION

	Page- Figure
Air Charge Temperature Sensor	4.9L Front lower intake manifold runner 133-2 5.0L Front lower intake manifold runner 136-4 5.8L Front lower intake manifold runner 136-4 7.5L Front lower intake manifold runner —
Canister Purge Solenoid	5.8L, 7.5L RH side engine —
EEC Clutch Switch	Above clutch pedal —
EEC Power Relay	Under plastic shield at the air cleaner support bracket —
EGR Vacuum Regulator Solenoid	4.9L at rear of engine on rocker cover bracket — 5.0L on bracket behind ignition coil 136-4 5.8L on bracket behind ignition coil 136-4 7.5L on bracket behind ignition coil —
EGR Valve Position Sensor	At EGR valve on intake manifold 133-1,135-3
Electronic Engine Control (EEC) Module	Behind LH kick panel —
Engine Coolant Temperature Sensor	4.9L at thermostat housing 134-2 5.0L at intake manifold 136-4 5.8L at intake manifold 136-4 7.5L at intake manifold —
Engine RPM Sensor (Diesel) .	At injection pump timing gear cover 138-6,137-5
Fuel Pump Relay	Under plastic shield at the air cleaner support bracket —
Fuse Link N	Near starter relay —
Fuse Link W	At EEC power relay —
Heated Exhaust Gas Oxygen Sensor	In communicator tube connecting both exhaust pipes 134-2,135-3
Knock Sensor	4.9L in cylinder block forward of the distributor 133-1 5.0L in cylinder block behind the intake manifold —

(Continued on next page)

quency signal to the **EEC Module**. With the ignition switch in the Key-On/Engine Off position, the MAP sensor measures the Barometric Pressure in the intake manifold. With the ignition switch in the Key-On/Engine-Running position, the MAP sensor measures the varying pressure (Vacuum) in the intake manifold.

The **Power Steering** pressure switch signals the **EEC Module** when the power steering pressure increases the load on the engine, to increase the idle speed (4.9L Auto. Trans. and 5.0L only).

The **EGR Valve Position (EVP) Sensor** signals the **EEC Module** with the position of the **EGR valve pintle** position.

The **Air Charge Temperature (ACT) Sensor** signals the **EEC Module** with the temperature of the air in the intake manifold.

The **Knock Sensor** signals the **EEC Module** to retard timing if the engine starts to detonate (4.9L and 5.0L only).

An **A/C Clutch Compressor (ACC) Signal** is used to indicate to the **EEC Module** when the A/C compressor is turned On. This will allow the **EEC Module** to increase the engine idle speed and/or compensate for the increased load.

The **Vehicle Speed Sensor** provides a frequency to the **EEC Module** to indicate vehicle speed. The **EEC Module** uses this input for idle speed control and decel fuel shutoff (4.9L, 5.0L, and 5.8L only).

TROUBLESHOOTING HINTS

CONDITION	POSSIBLE CAUSE	ACTION
• Intermittent Trouble Codes	• Loose EEC connector	• Clean/Tighten and check wiring

NOTE: The EEC-IV system retains any intermittent trouble codes stored within the last 40 engine starts. With this system, the memory is not erased when the key is turned to OFF. However, memory will be lost if the Battery is disconnected.

COMPONENT LOCATION

Page-
Figure

Manifold Absolute Pressure Sensor	On bracket above heater or A/C evaporator housing	—
Power Steering Pressure Switch	In power steering pressure hose near the steering gear	—
Thermactor Air Bypass Solenoid	4.9L at left rear of engine on rocker cover bracket	133-1
	5.0L on bracket behind ignition coil	136-4
	5.8L on bracket behind ignition coil	136-4
	7.5L on bracket behind ignition coil	—
Thermactor Air Diverter Solenoid	4.9L at left rear of engine on rocker cover bracket	133-1
	5.0L on bracket behind ignition coil	136-4
	5.8L on bracket behind ignition coil	136-4
	7.5L on bracket behind ignition coil	—
Throttle Air Bypass Valve Solenoid	On throttle body	133-1,136-4
Throttle Position Sensor ..	Connected to throttle body shaft	133-1,135-3

Refer to the **Location Index** in the back of the manual for connector, ground, diode and splice descriptions and locations.

The A/C demand (**ACD**) signal is used to indicate to the **EEC Module** when the climate control switch is in any mode requesting A/C. This will allow the **EEC Module** to increase the engine idle speed (4.9L only).

System Outputs

Receiving a signal from the **Engine RPM Sensor**, the **EEC Module** conditions this signal and provides a buffered engine RPM signal to the **Instrument Cluster Tachometer** (7.3L Diesel with E40D Transmission only).

Fuel flow is controlled by fuel injector solenoids (six in 6 Cyl. engine, eight in 8 Cyl. engine). The **EEC Module** regulates the amount of fuel injected into each cylinder by the on/off time of the injectors. The longer the on-time, the greater the fuel flow through the injectors. The **EEC Module** uses information received from the system input sensors to determine injector on/off-time.

Fuel pressure is built up by the Electric Fuel Pumps when the **EEC Module** supplies a ground through circuit 97 to the **Fuel Pump Relay**. With the **Ignition Switch** in START or RUN, the **EEC Power Relay** supplies voltage through circuit 361 R, to the **Fuel Pump Relay**. This voltage energizes the **Fuel Pump Relay**.

With power applied through the **EEC Power Relay** to the **Fuel Pump Relay**, and with the **Inertia Switch** closed, power is applied to the **Fuel Pumps**.

Current to the **In-Tank Fuel Pump** passes through a resistance wire and this pump, mounted in the fuel tank, pumps fuel at low (5 psi) pressure. Pressure is boosted by the **In-Line Fuel Pump**.

The efficiency of the catalytic converter is dependent upon the temperature and chemical make-up of exhaust gases. A **Thermactor** air system is used to supply secondary air to the exhaust manifold(s), to the catalyst or to the atmosphere, depending on engine conditions sensed by the **EEC Module** through the system inputs.

When the **Thermactor Air Bypass Solenoid** is OFF (de-energized), Thermactor air is dumped to the atmosphere rather than routed to the catalytic converter or exhaust manifold.

With the **Thermactor Air Bypass Solenoid** ON (energized) and the **Thermactor Air Diverter Solenoid** OFF (de-energized) Thermactor air is downstream (to the catalytic converter).

When the **Thermactor Air Bypass Solenoid** and the **Thermactor Air Diverter Solenoid** are ON (energized), Thermactor air is diverted to the exhaust manifold (upstream).

NOTE

The 7.5L has only a **Thermactor Air Bypass Solenoid**; thermactor air is either dumped (de-energized) or routed to the catalyst (energized).

The **Throttle Air Bypass Valve Solenoid** is an electro-mechanical device controlled by the **EEC Module**. It incorporates a solenoid which positions a variable-area metering valve. This valve is used to control both warm and cold engine air flow into the intake manifold. This allows the **EEC Module** to control the engine warm and cold speed, and allow for "no-touch" starting.

The **EGR Vacuum Regulator Solenoid** controls EGR valve movement. The **EEC Module** receives data from various sensors. It also checks existing valve position through the **EGR Valve Position Sensor** and calculates if the present EGR flow should be increased, maintained or decreased. The **EEC Module** then determines a proper duty cycle for the **EGR Vacuum Regulator Solenoid** on time to control the EGR valve position.

The **Thick Film Integrated IV (TFI-IV) Ignition Module** supplies the spark signal to the distributor through the ignition coil, and calculates the duration. It receives its control signal from the **EEC Module** through the spark output circuit (324 Y/LG).

E4OD Transmission

The **E4OD Transmission** supplies inputs to and receives outputs from the **EEC Module**.

INPUTS

The **E4OD Switch** is used to inform the **EEC Module** when a condition of overdrive cancel on the **E4OD** transmission has been requested.

The **Manual Lever Position Switch** provides the **EEC Module** with transmission lever position information for operation of the **E4OD** transmission.

The **Transmission Oil Temperature Sensor** is used to control shift points as a function of temperature.

The **4-Wheel Drive Indicator Switch** informs the **EEC Module** of 4X4 Low selection.

OUTPUTS

The **Converter Clutch Control Solenoid** controls converter clutch lockup.

The **Coast Clutch Control Solenoid** permits engine braking in third gear and overdrive.

The **Electronic Pressure Control** regulates internal line pressure.

The **Shift Solenoid #1** and **Shift Solenoid #2** control the gear selection of the transmission.

Refer to the **Engine/Emissions Diagnosis Manual, volume H, and Technical Service Bulletins** for complete **EEC-IV** test procedures using special Rotunda test equipment.





Figure 1 — E40D Transmission

52 FUEL INJECTOR COOLING FAN (4.9L ENGINE)



HOW THE CIRCUIT WORKS

The **Injector Blower Motor** will operate for a maximum of 15 minutes with the **Ignition Switch** in OFF and the **Cooling Fan Temperature Switch** closed. The **Injector Blower Relay** will disable the **Cooling Fan Motor** if the **Cooling Fan Temperature Switch** opens before 15 minutes or if the **Ignition Switch** is turned to RUN. Proper operation of the **Cooling Fan Motor** system can be established by grounding circuit **743 BK/LB** at the **VIP** connector (the **Ignition Switch** must be in OFF) and timing the fan ON time. The maximum ON time is 15 minutes.

Refer to section 28-01 of the shop manual.

COMPONENT LOCATION

Page-
Figure


Cooling Fan Motor	RH inner fender	—
Injector Blower Relay	Behind I/P near fuse panel	—
Cooling Fan Temperature Switch	Clipped to fuel rail near number one fuel injector	134-2

Refer to the **Location Index** in the back of the manual for connector, ground, diode and splice descriptions and locations.

TROUBLESHOOTING HINTS

CONDITION	POSSIBLE CAUSE	ACTION
<ul style="list-style-type: none"> • Cooling Fan doesn't operate 	<ul style="list-style-type: none"> • No voltage at Y/LB wire of Injector Blower Relay • No or poor continuity of BK wire from Cooling Fan Motor to G802 • No voltage at Cooling Fan Motor • Inoperative Cooling Fan Motor • Inoperative Cooling Fan Temperature Switch 	<ul style="list-style-type: none"> • Check wiring and Fuse 16. • Check for loose connection at ground and open in BK wire. • Check for open in PK/W wire between Injector Blower Relay and Cooling Fan Motor. • Apply voltage and ground to motor. If motor does not operate, replace with known good motor. • Bypass switch by shorting across connector terminals. If motor operates, replace switch.

54 HEADLAMPS



HOW THE CIRCUIT WORKS

Battery voltage is applied at all times through **Fuse Link J** to the **Main Light Switch**. When the **Main Light Switch** is pulled to HEAD, voltage is applied through the **Light Switch** and the **Dimmer Switch** to the **Headlamps**. The **Headlamps** will operate in either HI or LO Beam depending upon the position of the **Dimmer Switch**. The **Headlamps** are permanently grounded through **G801** and **G802**.

When the **Dimmer Switch** is in HI, voltage is also applied to the **High Beam Indicator**. The Indicator is permanently grounded through **G701**.

Refer to section 32-01 of the shop manual.

COMPONENT LOCATION

Page-
Figure

Main Light Switch	LH side of I/P	102-2
Refer to Component Testing Page 141 for additional testing details.		
Dimmer Switch	On floor pan LH side of cab	—

Refer to the **Location Index** in the back of the manual for connector, ground, diode, and splice description and locations.

TROUBLESHOOTING HINTS

CONDITION	POSSIBLE CAUSE	ACTION
<ul style="list-style-type: none"> • No headlamps, but park lamps function 	<ul style="list-style-type: none"> • No voltage at R/Y wire of Dimmer Switch • No voltage at R/BK wire of Dimmer Switch 	<ul style="list-style-type: none"> • Check continuity of wire and Light Switch/replace or repair • Repair/Replace Switch
<ul style="list-style-type: none"> • No HI or LO Beam on one side 	<ul style="list-style-type: none"> • Poor ground connection on affected side 	<ul style="list-style-type: none"> • Clean/Tighten






Figure 1 — L.H. Headlamp Assembly

56 EXTERIOR LAMPS (PARK, MARKER, LICENSE)



58 EXTERIOR LAMPS (BODY MARKER, TRAILER)



HOW THE CIRCUIT WORKS

When the **Main Light Switch** is turned to PARK or HEAD, battery voltage is applied through **Fuse 4** to the **Park, Marker, and License Lamps**. All of these lamps are permanently grounded and light whenever voltage is applied.

COMPONENT LOCATION

Page-
Figure

Fuse Link G	Near starter relay	—
Marker Lamp Relay	Attached to dash panel	—
Trailer Lamp Relay	Attached to dash panel	—

Refer to section 32-01 of the shop manual.

Refer to the **Location Index** in the back of the manual for connector, ground, diode and splice descriptions and locations.

TROUBLESHOOTING HINTS

CONDITION	POSSIBLE CAUSE	ACTION
<ul style="list-style-type: none"> No exterior lamps light 	<ul style="list-style-type: none"> No voltage at T/W wire of Main Light Switch C701 is loose No voltage at BR wire or lamps Defective Main Light Switch 	<ul style="list-style-type: none"> Check Fuse 4 and wiring Tighten/Replace Check for open in BR wire Replace switch as required
<ul style="list-style-type: none"> One lamp does not light 	<ul style="list-style-type: none"> Blown bulb Frayed or damaged wires or loose wires 	<ul style="list-style-type: none"> Replace bulb as required Repair as required




Figure 1 - Top Of Cab

60 EXTERIOR LAMPS




Figure 2 — LH Side Of Rear Crossmember




Figure 3 — RH Side Of Rear Crossmember




Figure 4 — Rear Frame Crossmember




Figure 5 — Center Of Rear Bumper




Figure 6 — RH Side Of Rear Crossmember




Figure 7 — Lower LH Cowl Area




Figure 8—LH Rear Fender Well for Dual Wheels (RH Similar)






Figure 9—Rear LH Side Frame Crossmember

62 TURN/STOP/HAZARD LAMPS





HOW THE CIRCUIT WORKS

Turn Signals and Hazard Flashers

With the Ignition Switch in RUN, voltage is applied through Fuse 5 and the Turn Signal Flasher to the Turn/Hazard Switch. When the Turn/Hazard Switch is closed for LH, RH, or Hazard Indicator operation, voltage is applied through the Switch to the lamps. All of these lamps are permanently grounded.

Stoplamps

Voltage is applied through Fuse 1 to the Stoplamp Switch. When the Brake Pedal is pressed, the Stoplamp Switch closes, and voltage is applied through the closed contacts of the Turn/Hazard Switch to the Stoplamps. These lamps are permanently grounded.

COMPONENT LOCATION

Hazard Flasher	In rear of fuse panel	—
Stoplamp Switch	Mounted to bracket at top of brake pedal	79-2
Turn Signal Flasher	In front of fuse panel	16-1
Turn/Hazard Switch	Mounted in steering column	—

Refer to Component Testing Page 142 for additional testing details.

Refer to the **Location Index** in the back of the manual for connector, ground, diode and splice descriptions and locations.

Refer to section 32-01 of the shop manual.

TROUBLESHOOTING HINTS

CONDITION	POSSIBLE CAUSE	ACTION
<ul style="list-style-type: none"> Hazard Flashers do not work 	<ul style="list-style-type: none"> No voltage at R/W Hazard Flasher wire Defective Hazard Flasher No voltage at C305 W/R wire Defective Turn/Hazard Switch 	<ul style="list-style-type: none"> Check Fuse 1 and wiring Replace with known good flasher Repair open in wiring Replace with known good switch
<ul style="list-style-type: none"> No Turn Indicators work 	<ul style="list-style-type: none"> No voltage at P/O wire of Turn Signal Flasher No voltage at C305 LB wire Defective Turn Signal Flasher Defective Turn/Hazard Switch 	<ul style="list-style-type: none"> Check Fuse 5 and wiring Repair open in wiring Replace with known good flasher Replace as required
<ul style="list-style-type: none"> No Stoplamps 	<ul style="list-style-type: none"> No voltage at LG/R wire of Stoplamp Switch Defective Stoplamp Switch 	<ul style="list-style-type: none"> Check Fuse 1 and wiring Replace with known good switch

TROUBLESHOOTING HINTS

CONDITION	POSSIBLE CAUSE	ACTION
<ul style="list-style-type: none"> • One Turn Indicator not working 	<ul style="list-style-type: none"> • Blown bulb • No voltage at socket • Poor ground • Defective Turn/Hazard Switch 	<ul style="list-style-type: none"> • Replace bulb • Repair opens in wiring • Clean or repair open in BK ground wire • Replace switch as required






Figure 1 – At Rear Crossmember

66 BACKUP LAMPS



HOW THE CIRCUIT WORKS

With the **Ignition Switch** in RUN or START, battery voltage is applied through **Fuse 5** to the **Backup Lamp Switch**. When the transmission is placed in REVERSE, the **Backup Lamp Switch** closes and voltage is applied to the LH and RH **Backup Lamps**. These lamps are permanently grounded through **G801**.

Refer to section 32-01 of the shop manual.

COMPONENT LOCATION

Page-
Figure

Backup Lamp Switch	Part of manual transmission assembly or neutral start switch	67-1
Turn Signal Flasher	In front of fuse panel	14-1

Refer to the **Location Index** in the back of the manual for connector, ground, diode and splice descriptions and locations.

TROUBLESHOOTING HINTS

CONDITION	POSSIBLE CAUSE	ACTION
<ul style="list-style-type: none"> No Backup Lamps light 	<ul style="list-style-type: none"> No voltage at P/O wire of Backup Lamp Switch No voltage at BK/PK wire of Backup Lamp Switch with transmission in Reverse 	<ul style="list-style-type: none"> Check Fuse 5 and wiring for opens Replace Backup Lamp Switch
<ul style="list-style-type: none"> One Backup Lamp will not light 	<ul style="list-style-type: none"> Blown bulb Check socket for corrosion No voltage at socket hot pin Poor ground connection from bulb 	<ul style="list-style-type: none"> Replace bulb Clean/Replace Repair open in BK/PK wire of socket Clean/Tighten connection or repair open in wiring
<ul style="list-style-type: none"> Backup Lamps stay on 	<ul style="list-style-type: none"> Defective Switch Short to voltage 	<ul style="list-style-type: none"> Replace as required Repair wiring






Figure 1 - Manual Transmissions

68 COURTESY/DOME/CARGO LAMPS



SEE CHARGE/
POWER DISTRIBUTION
PAGE 19



70 COURTESY/DOME/CARGO LAMPS

HOW THE CIRCUIT WORKS

Battery voltage is applied at all times to the **Main Lamp Switch, Door Jamb Switches, Glove Compartment Switch** and **Dome Switch** through **Fuse 4** and **Fuse 8**. Battery voltage is also applied in ACCY or RUN through **Fuse 6** to the **Cargo Lamp Switch**. When the switches are closed, voltage is applied through the switches to the lamps. All of these lamps are permanently grounded.

Refer to section 32-01 of the shop manual.

COMPONENT LOCATION

Page-
Figure

Door Jamb Switches	LH lower cowl, near fuse panel	—
Main Light Switch	LH side of I/P	102-2

Refer to Component Testing Page 141 for additional testing details.

Refer to the **Location Index** in the back of the manual for connector, ground, diode and splice descriptions and locations.

TROUBLESHOOTING HINTS

CONDITION	POSSIBLE CAUSE	ACTION
<ul style="list-style-type: none"> Cargo Lamp, Dome Lamp, Glove Compartment do not light 	<ul style="list-style-type: none"> No voltage at LG/Y wire of switches 	<ul style="list-style-type: none"> Check fuse 8 and LG/Y wire of switches
<ul style="list-style-type: none"> Hoodlamps and Map Lamps do not light 	<ul style="list-style-type: none"> No voltage at BR wire of switches 	<ul style="list-style-type: none"> Check fuse 4, Main Light Switch and BR wire of switches
<ul style="list-style-type: none"> Single lamp doesn't light 	<ul style="list-style-type: none"> Blown bulb Socket corrosion Defective switch 	<ul style="list-style-type: none"> Replace bulb Clean/Replace Replace switches as required




Figure 1 – Cargo Area of Bronco




Figure 2 - LH Quarter Panel of Super Cab




Figure 3 - LH Quarter Panel of Regular Cab

HOW THE CIRCUIT WORKS

Battery voltage is applied at all times through **Fuse 4** to the **Main Light Switch**. When the **Main Light Switch** is turned to PARK or HEAD, voltage is applied through the switch to the **Instrument Illumination Lamps**. The amount of voltage, and in turn the intensity of the lamps, can be adjusted by rotating the **Dimmer Switch** of the **Main Light Switch**.

Refer to section 32-01 of the shop manual.

COMPONENT LOCATION


Main Light Switch I/P, left of steering column 102-2
 Refer to Component Testing Page 141 for additional testing details.

Refer to the **Location Index** in the back of the manual for connector, ground, diode and splice descriptions and locations.

TROUBLESHOOTING HINTS

CONDITION	POSSIBLE CAUSE	ACTION
<ul style="list-style-type: none"> • No Instrument Lamps light 	<ul style="list-style-type: none"> • No voltage at T/W wire of Main Light Switch • No voltage at LB/R wire of lamps • Defective Dimmer Switch of Main Light Switch • No or poor continuity at circuit connections 	<ul style="list-style-type: none"> • Check Fuse 4 and wiring • Check Fuse 17, wiring and Main Light Switch • Replace with known good Main Light Switch • Clean/Tighten connections
<ul style="list-style-type: none"> • One Lamp does not light 	<ul style="list-style-type: none"> • Blown bulb • Socket corrosion 	<ul style="list-style-type: none"> • Replace bulb as required • Clean/Replace socket

74 WARNING INDICATORS (BRAKE, IGNITION KEY, SEATBELT)



HOW THE CIRCUIT WORKS

Warning Indicators

The "Engine" Warning Indicator comes on with the Ignition Switch in RUN or START with low oil pressure and/or high coolant temperature.

The Brake Warning Indicator goes on:

1. With the Ignition Switch in START, to test the bulb. (This connection is closed just before the Starter Relay pulls in.)
2. When the brakes are applied and either front or rear brake system has failed (low pressure).
3. When the Parking Brake Switch closes.

With the Ignition Switch in START, the Check Engine Warning Indicator lights to test the bulb. With the Ignition Switch in RUN, the Check Engine Warning Indicator lights when a malfunction has occurred in the EEC system.

Seatbelt Warning

With the Ignition Switch in RUN, voltage is applied through Fuse 18, and the "Fasten Belts" Indicator for 4 to 8 seconds, whether belts are buckled or not. The buzzer/chime will sound during this time only if the driver's belt is not buckled.

Key Warning

Battery voltage is applied at all times through

COMPONENT LOCATION

	Page-Figure
Brake Sensor	Part of master cylinder —
Brake Warning Indicator ..	Part of instrument cluster —
Check Engine Warning Indicator	Part of instrument panel —
Ignition Switch	Attached to steering column —
Refer to Component Testing Page 000 for additional testing details.	
Inferred Mileage Sensor Module	Attached to instrument to left of steering column —
Key Switch	Part of ignition switch —
Parking Brake Switch	On parking brake bracket —
Seatbelt Switch	In driver's seatbelt buckle —
Seatbelt Warning Buzzer/Chime	Attached in left center of I/P —

Refer to the Location Index in the back of the manual for connector, ground, diode and splice descriptions and locations.

Fuse 8 to the LH Front Door Jamb Switch. When the LH Front Door is opened, the Door Jamb Switch closes and battery voltage is applied through the Warning Buzzer/Chime to the Key Switch. Battery voltage is also applied at all times through Fuse 4 to the Main Light Switch. When the Main Light Switch is turned to PARK or HEAD, voltage is applied through the Switch to the Warning Buzzer/Chime. Whenever the key

is in the Ignition, the Key Switch is closed and provides a ground for the Warning Buzzer/Chime. Therefore, with the Lights ON and/or the LH Front Door open, the Warning Buzzer/Chime will sound if the key is in the Ignition.

Refer to section 33-01 of the shop manual.

TROUBLESHOOTING HINTS — WARNING INDICATORS

CONDITION	POSSIBLE CAUSE	ACTION
<ul style="list-style-type: none"> • Any Warning Indicator lights when systems are normal 	<ul style="list-style-type: none"> • Defective switch • Shorts to ground in wiring between Instrument Cluster and any switch 	<ul style="list-style-type: none"> • Check switches providing ground path to indicator • Check resistance of wiring between cluster and chassis ground
<ul style="list-style-type: none"> • Warning Indicator doesn't light 	<ul style="list-style-type: none"> • Blown bulb • No continuity from printed circuit to ground • No voltage at R/Y wire of C208B • Open in Instrument Cluster printed circuit 	<ul style="list-style-type: none"> • Replace bulb • Check for any open wires or switches • Check for open in wire or Fuse 18 • Repair/Replace as required


76 WARNING INDICATORS (BRAKE, OIL, IGNITION KEY, SEATBELT)

TROUBLESHOOTING HINTS — SEATBELT WARNING

CONDITION	POSSIBLE CAUSE	ACTION
<ul style="list-style-type: none"> No Seatbelt Warning Indicator Buzzer/Chime operation 	<ul style="list-style-type: none"> No voltage at R/Y buzzer/chime wire No continuity to ground through BK wire 	<ul style="list-style-type: none"> Check Fuse 18 and wiring Check for open in BK wire
<ul style="list-style-type: none"> Seatbelt Indicator does not light 	<ul style="list-style-type: none"> Blown Bulb No voltage at DG/LG wire of C208A when buzzer is on No continuity from BK wire of C208A to G701 Defective buzzer/chime 	<ul style="list-style-type: none"> Replace bulb Check for open in wire Check for open in BK wire Replace with known good buzzer/chime
<ul style="list-style-type: none"> Buzzer/Chime doesn't sound 	<ul style="list-style-type: none"> No continuity to ground from BR/LB wire of buzzer/chime No voltage on R/Y wire at buzzer/chime Defective buzzer/chime 	<ul style="list-style-type: none"> Check for open in BK wire Check for open in R/Y wire or Fuse 18 Replace with known good buzzer/chime

TROUBLESHOOTING HINTS — KEY WARNING

CONDITION	POSSIBLE CAUSE	ACTION
<ul style="list-style-type: none"> Key Warning Buzzer/Chime does not sound 	<ul style="list-style-type: none"> No voltage at R/PK wire No continuity to ground from BK/PK wire of buzzer/chime 	<ul style="list-style-type: none"> Check Fuse 8, R/PK buzzer wire and LH Door Jamb Switch for open Apply ground to both ground pins of buzzer/chime. If buzzer/chime operates, repair opens in ground



HOW THE CIRCUIT WORKS

With the **Ignition Switch** in START or RUN, the **Diesel Warning Indicators** are powered through **Fuse 18**. With the **Ignition Switch** in START, the indicators are grounded for a bulb test.

The **Brake Warning Indicator** goes on:

1. With the **Ignition Switch** in START, to test the bulb. (This connection is closed just before the **Starter Relay** pulls in.)
2. When the brakes are applied and either front or rear brake system has failed (low pressure).
3. When the **Parking Brake Switch** closes.
4. When the **Low Vacuum Warning Switch** closes.

The **Low Vacuum Warning Switch** (not used with Hydroboost brake system) closes when manifold vacuum falls below 10 inches. The **Parking Brake Switch** closes when the parking brake is engaged.

There is a 7-second delay after the **Low Vacuum Warning Switch** opens or closes to prevent nuisance flashing of the Brake Indicator. Note that a belt driven vacuum pump is used with the diesel engine to supply vacuum. When the engine has been off for several minutes or more and vacuum has bled down, the **Brake Indicator** will come on as soon as the **Ignition Switch** is turned to RUN. The indicator will stay on even after the engine is started until vacuum has reached a normal level.

CAUTION

Do not drive vehicle until the brake indicator goes out. Greatly increased pedal effort is required to stop without vacuum assistance for the brakes.

COMPONENT LOCATION

	Page-Figure
Anti-lock Brake Module . . .	Behind I/P left of center —
Anti-lock Brake Indicator . . .	Part of instrument cluster —
Brake Warning Sensor . . .	Part of master cylinder —
Fuel Filter Indicator	Part of instrument cluster —
Coolant Temperature Sensor	On LH front of engine 134-2,136-4
Diesel/Warning Lamp Module	Behind LH side of I/P near fuse panel —
Fuel Water Switch	Part of fuel filter on upper RH front of engine —
Low Vacuum Warning Switch (Not with Hydroboost Brake System)	On RH fender apron —
Overheat Warning Switch . . .	On LH side of engine 137-5
Parking Brake Switch	On parking brake bracket —

Refer to the **Location Index** in the back of the manual for connector, ground, diode and splice descriptions and locations.

The **Fuel Water Switch** senses water in the fuel/water separator sediment bowl. The switch will close with water in the sediment bowl and the **Water-In-Fuel Indicator** will go on. See Shop Manual section 25-50 for draining instructions.

Refer to section 33-01 of the shop manual.

TROUBLESHOOTING HINTS

CONDITION	POSSIBLE CAUSE	ACTION
<ul style="list-style-type: none"> Any Warning Indicator lights when systems are normal 	<ul style="list-style-type: none"> Defective switch Shorts to ground in wiring between warning bulb and switch 	<ul style="list-style-type: none"> Check switches providing ground path for indicator Repair shorts in wiring as required
<ul style="list-style-type: none"> Any Warning Indicator doesn't light 	<ul style="list-style-type: none"> Blown bulb Poor ground connection from bulb No voltage at R/Y, R/W or BK/PK wire at affected bulb with Ignition Switch in RUN 	<ul style="list-style-type: none"> Replace bulb Clean/Tighten connection or repair open in wiring Repair opens in wiring




Figure 1 — Seat Belt Wiring (Standard Cab)





Figure 2 — Stop Lamp Switch

80 ANTI-LOCK BRAKES



HOW THE CIRCUIT WORKS

The **Anti-lock Brake System** is powered thru **Fuse 10** with the **Ignition Switch** in ACCY or RUN. The **Anti-lock Indicator** is powered thru **Fuse 18**.

The **Anti-lock Brake Module** processes signals from the **Anti-lock Rear Axle Sensor**, **Stop Lamp Switch** and **4x4 Transfer Case Indicator Switch** to energize the **Rear Anti-lock Brake Proportioning (RABS) Valve** to first isolate the **Rear Wheel Cylinders** from the **Master Cylinder**. If the signals indicate that rear wheel lock-up is still impending then the **RABS Valve** is energized with rapid pulses to bleed sufficient fluid from the isolated rear brake system to prevent lock-up.

Refer to section 12-01 of the shop manual.

COMPONENT LOCATION


		Page- Figure
Anti-lock Brake Indicator . . .	Part of instrument cluster	—
Anti-lock Brake Module . . .	Behind I/P left of center	—
Anti-lock Rear Axle Sensor	At rear axle	—
Rear Anti-lock Brake Proportioning Valve	Inside of LH frame rail behind # crossmember	—
4x4 Transfer Case Indicator Switch	On transfer case	—

Refer to the **Location Index** in the back of the manual for connector, ground, diode and splice descriptions and locations.


TROUBLESHOOTING HINTS

CONDITION	POSSIBLE CAUSE	ACTION
<ul style="list-style-type: none"> • Anti-lock Indicator is lit. 	<ul style="list-style-type: none"> • Defect in Anti-lock Brake System 	<ul style="list-style-type: none"> • Ground test connector terminal C380 to obtain a diagnostic code from the Anti-lock Indicator. See Shop Manual Section 12-01 for more information.

82 ELECTRONIC SHIFT — 4-WHEEL DRIVE/4-WHEEL DRIVE INDICATOR



ELECTRONIC SHIFT — 4-WHEEL DRIVE/4-WHEEL DRIVE INDICATOR 83



HOW THE CIRCUIT WORKS 4-WHEEL DRIVE INDICATOR

With the **Ignition Switch** in ACCY or RUN and 4-wheel drive engaged, battery voltage is applied through **Fuse 18** to the **4-Wheel Drive Indicator** to light the appropriate indicator lamp.

Refer to section 33-01 of the shop manual.

ELECTRONIC SHIFT — 4-WHEEL DRIVE

When the **Shift Control Switch** is placed in 4x4 or Low, the **Electronic Shift Control Module** will analyze information from the **Shift Position Sensors** to determine their current positions. It will also analyze information inputs from the **Transfer Case Speed Sensor** and the **Automatic Transmission Switch**. The **Electronic Shift Control Module** will then activate the **Transfer Case Motor** to produce the desired shift, and the **4-Wheel Drive Indicator** will be illuminated.

Refer to section 16-01 of the shop manual.

COMPONENT LOCATION

		Page- Figure
Automatic Transmission Switch	In automatic transmission	—
Electronic Shift Control Module	RH cowl panel	85
Shift Control Switch	On LH side of I/P	—
Hi Indicator Lamp	Part of instrument cluster	—
Lo Indicator Lamp	Part of instrument cluster	—
Shift Position Sensors	Inside transfer case	85
Transfer Case Clutch Coil	Inside transfer case	—
Transfer Case Motor	Inside transfer case	85
Transfer Case Speed Sensor	Inside transfer case	—
4 Wheel Drive Indicator Switch	On transfer case	—

Refer to the **Location Index** in the back of the manual for connector, ground, diode and splice descriptions and locations.

TROUBLESHOOTING HINTS — 4-WHEEL DRIVE INDICATOR

CONDITION	POSSIBLE CAUSE	ACTION
<ul style="list-style-type: none"> • Indicator does not light 	<ul style="list-style-type: none"> • No voltage at R/Y wire of warning lamps • Blown Bulb 	<ul style="list-style-type: none"> • Check Fuse 18 and wiring • Replace bulb

TROUBLESHOOTING HINTS — 4-WHEEL DRIVE INDICATOR

CONDITION	POSSIBLE CAUSE	ACTION
<ul style="list-style-type: none"> Electronic Shift does not operate 	<ul style="list-style-type: none"> No voltage at BK/W or W/P wires of Electronic Shift Module Defective Shift Control Switch Defective Transfer Case Motor Frayed or damaged wires or loose connections 	<ul style="list-style-type: none"> Check Circuit Breaker 12, Fuse 6 and wiring Replace switch as required Replace as required Repair as required




Figure 1 — Electronic Shift Control Module






Figure 2 — At Transfer Case

FUEL TANK SELECTOR/GAUGES (FUEL, COOLANT OIL) (DUAL TANKS) 87



SEE GROUNDS
PAGE 5, 6

88 FUEL TANK SELECTOR/GAUGES (FUEL, COOLANT OIL) (DUAL TANKS)



90 FUEL TANK SELECTOR/GAUGES

HOW THE CIRCUIT WORKS

With the **Ignition Switch** in ACCY or RUN, circuit 640 R/Y from **Fuse 18** powers the **Fuel, Coolant Temperature, Oil Pressure Gauges, Volt Meter** and, **Tachometer** if so equipped.

The **Fuel Gauge** is connected to a **Fuel Gauge Sender**. The **Sender** is a variable resistor connected to a float in the fuel tank. When the fuel is low, resistance is high; when fuel is high, resistance is low.

The **Electric Fuel Pump Control** for **Dual Tanks** consists of three electric fuel pumps. Two low pressure (**C68 In-Tank Fuel Pumps**) located in both the front and rear tanks, pump fuel into a reservoir. A high pressure **In-Line Fuel Pump** then takes the fuel from the **Reservoir** to the **Fuel Injectors**.

This system allows fuel to be drawn from either the **Front** or **Rear Fuel Tank Unit**. With the **Ignition Switch** in START or RUN, voltage is applied through **Fuse Link M** to the **Fuel Pump Relay**. When the **Fuel Pump Relay** receives a signal from the **EEC Module** and the **Inertia Switch** is closed, power is supplied to the **In-Line Fuel Pump**, and depending on which position the **Fuel Tank Selector Switch** is in (FRONT OR REAR), to either the **Front** or **Rear In-Tank Fuel Pump**.

The **Fuel Tank Selector Switch** controls which **Fuel Tank Unit** is used. When turned to the Front position, power flows through the Front contacts of the **Fuel Tank Selector Switch** to the fuel pump of the **Front Fuel Tanks**. The sender in the **Front Fuel Tank Unit** is connected simultaneously to the **Fuel Gauge**.

When the **Fuel Tank Selector Switch** is turned to REAR, the **Fuel Pump** in the **Rear Fuel Tank Unit** is connected simultaneously to the **Fuel Gauge**.

When the **Fuel Tank Selector Switch** for 7.3L with the optional **Fuel Gauge** is connected to the **Front Tank Gauge Sender**. When the switch is in the REAR position, the **Fuel Gauge** is connected to the **Rear Tank Fuel Gauge Sender**. Voltage is applied through **Fuse 15** and the switch

COMPONENT LOCATION

	Page- Figure
Coolant Temperature Gauge	Part of instrument cluster
Coolant Temperature Switch (4.9L)	Behind #6 exhaust manifold on engine block
(5.0L and 5.8L)	LH side of intake manifold
(7.3L Diesel)	LH front of engine
(7.5L)	LH side of intake manifold
Engine RPM Sensor (7.3L Diesel)	At injection pump timing gear cover
Engine Warning Indicator	Part of instrument cluster
Engine Warning Indicator Module	Part of instrument cluster
Front Tank Fuel Gauge Sender	On tank in front of rear axle
Fuel Tank Selector Switch	Center of I/P
Fuel Tank Selector Valve Solenoid	On LH side frame member behind cab
Inertia Switch	LH dash panel above brake pedal
Oil Pressure Gauge	Part of instrument cluster
Oil Pressure Sender (4.9L)	On engine block to rear of oil filter
(5.0L, 5.8L, 7.5L)	LH front of engine
(7.3L Diesel)	Rear of engine
Rear Tank Gauge Sender	On tank behind rear axle
Tachometer	Part of instrument cluster

Refer to the **Location Index** in the back of the manual for connector, ground, diode and splice descriptions and locations.

to energize the motor-driven **Tank Selector Valve**. Fuel is then drawn from the rear tank.

The selector valves for the 7.3L engines are motor driven valves, used to switch the **Fuel Gauge** between front and rear sending units as well as to switch fuel sources. The **Selector Switch** switches the sending units and **In-Tank Fuel Pumps** for the 4.9L, 5.0L, 5.8L and 7.5L

engines.

The **Oil Pressure Gauge** is connected to a 20 ohm resistor and **Oil Pressure Switch**. At low oil pressure, the switch opens causing the gauge to indicate low. At proper oil pressure, midscale normal oil pressure. The resistor is located on the instrument clusters printed circuit board.

The **Coolant Temperature Gauge** connects to

the **Coolant Temperature Sender**. The sender is a temperature-sensitive variable resistor. When the coolant temperature is low, resistance is high; when coolant temperature is high, resistance is low.

Refer to section 24-01 of the shop manual.

TROUBLESHOOTING HINTS

CONDITION	POSSIBLE CAUSE	ACTION
<ul style="list-style-type: none"> Fuel Tank Selector Switch does not work 	<ul style="list-style-type: none"> No voltage at R, Y/W or R/W wires of switch Defective switch 	<ul style="list-style-type: none"> Check Fuses 15 and 18 and wiring Replace switch as required
<ul style="list-style-type: none"> One Gauge does not work 	<ul style="list-style-type: none"> Poor ground connection to BK wire of sender Broken or corroded terminals at sender Open circuit in gauge or wiring 	<ul style="list-style-type: none"> Clean/Tighten connection or repair any open in wiring Clean/Replace Replace gauge or repair open in wiring
<ul style="list-style-type: none"> Incorrect gauge readings 	<ul style="list-style-type: none"> Gauge out of calibration Gauge erratic 	<ul style="list-style-type: none"> Check gauge to read full at 145 ohms, empty at 22.5 ohms. Check sender resistance at 154 to 162 ohms at full stop and 9 to 18 ohms at empty stop.






Figure 1 — 6 Port Fuel Tank Selector Valve, LH Side of Mainframe, Aft of Cab — 7.3L Diesel

92 ELECTRIC FUEL PUMP CONTROL (SINGLE TANK)



HOW THE CIRCUIT WORKS

The fuel delivery system consists of two electric fuel pumps. A low pressure **In-Tank Fuel Pump** which pumps fuel into a reservoir, and a high pressure In-Line Pump, which takes fuel from the **Reservoir** and pumps fuel to the **Fuel Injectors**.

With the **Ignition Switch** in START or RUN, Voltage is applied to **Fuel Pump Relay** through **Fuse Link M**. When the **Fuel Pump Relay** receives a signal from the **EEC Module** and with the **Inertia Switch** closed, power is applied to the **Fuel Pumps**.

When voltage is applied to the low pressure **Fuel Pump**, the **Reservoir** is filled with fuel. This **Reservoir** assures that adequate fuel flow is

COMPONENT LOCATION

Page-
Figure

Fuel/Gage Sender and Pump	At tank in front of rear axle	94-10, 11, 12
Inertia Switch	LH dash panel above brake pedal	—

Refer to the **Location Index** in the back of the manual for connector, ground, diode and splice descriptions and locations.

available to the high pressure **Fuel Pump** when climbing steep grades and during hard cornering, when the **In-Tank Fuel Pump** may be starved of fuel.

Refer to section 24-01 of the shop manual.

TROUBLESHOOTING HINTS

CONDITION	POSSIBLE CAUSE	ACTION
<ul style="list-style-type: none"> • Fuel Pump doesn't work 	<ul style="list-style-type: none"> • No voltage at PK/BK wire of Fuel Pump • Poor ground connection to BK wire • Defective Fuel Pump Cutoff Relay • Open Inertia Switch 	<ul style="list-style-type: none"> • Check Fuse Link M and wiring • Clean/Tighten or repair open in wiring • Replace with known good relay • Reset as required





Figure 10 — Rear Tank (Behind Rear Axle)
(Bronco Only)



DIESEL MODELS




Figure 11 — Plastic Fuel Tank
(F-Series)





Figure 12 — Metal Fuel Tank
(F-Series)



HOW THE CIRCUIT WORKS

HORNS

When the vehicle is equipped with speed control, battery voltage is applied at all times to the coil of the **Horn Relay** through **Fuse 6** and the **Speed Control Amplifier**. When the **Horn Switch** is closed, a ground is supplied through the steering column and the **Horn Relay** is pulled closed. Battery voltage is now applied through **Fuse 16** and the closed contacts of the **Horn Relay** to the case grounded **Horns**. If the vehicle is not equipped with speed control, battery voltage is applied at all times through **Fuse 16**. When the **Horn Switch** is closed, a ground is supplied through the case grounded **Horns** and the **Horns** sound.

Refer to section 35-01 of the shop manual.

COMPONENT LOCATION

Page-
Figure

Cigar Lighter	Center of I/P	—
Horns	LH front of radiator support	97-1
Horn Relay/Buss-Bar	Near speed control amplifier	—
Horn Switch	In steering wheel hub assembly	—
Speed Control Amplifier ..	Behind I/P at RH side of steering column	—
Speed Control Switch	Mounted in steering wheel hub assembly	—

Refer to the **Location Index** in the back of the manual for connector, ground, diode, and splice descriptions and locations.

CIGAR LIGHTER

Voltage is applied at all times to the Cigar Lighter. Pushing in the Cigar Lighter closes the switch and allows current to flow through the

heating element. The element opens the switch when it is heated.

Refer to section 35-01 of the shop manual.

TROUBLESHOOTING HINTS

CONDITION	POSSIBLE CAUSE	ACTION
<ul style="list-style-type: none"> Horn does not sound 	<ul style="list-style-type: none"> No voltage at Y/LB wire of Horn Relay or Horn Buss-Bar No voltage LB/BK wire of Horn Relay Defective Horn Relay No continuity through Horn Buss-Bar Defective Horn Switch Poor ground connection at steering column Horn out of adjustment Defective Horn 	<ul style="list-style-type: none"> Check Fuse 16 and wiring Check Fuse 6 and wiring Replace with known good Relay Check continuity through buss-bar and replace if necessary Check continuity through switch and replace if necessary Repair connection Turn adjusting screw on Horn counterclockwise 1/4 to 3/8 turn and secure Replace with known good Horn

TROUBLESHOOTING HINTS — CIGAR LIGHTER

CONDITION	POSSIBLE CAUSE	ACTION
<ul style="list-style-type: none">• Cigar Lighter doesn't work	<ul style="list-style-type: none">• No voltage at Y/LB wire of Cigar Lighter• Poor continuity to ground at lighter shell	<ul style="list-style-type: none">• Check Fuse 16 and wiring• Clean/Tighten connection and check BK wire for opens




Figure 1 - Forward of Radiator Support, Single Bracket Mounting Dual Horns





Figure 2 - Behind LH Side of I/P

98 WINDSHIELD WIPER/WASHER



HOW THE CIRCUIT WORKS

The **Windshield Wiper/Washer Switch** has both a momentary washer switch and wiper switch. The wiper switch has three positions: OFF, and LO and HI speeds.

Washer Operation—Current flows directly to the **Washer Pump** motor as long as the washer switch is depressed.

Wiper Operation—The wipers are controlled by the three-position wiper switch and the wiper motor switch. When the wipers are turned OFF, they continue to operate until they return to the PARK position of the wiper motor switch.

In LO or HI current flows through the wiper switch, into the L or H terminal of the **Wiper Motor**, and grounds through the C terminal.

When parking current flows through:

1. the R wire to the RUN contact of the wiper motor switch;
2. through the wiper motor switch and the BK/PK wire to the wiper switch;

COMPONENT LOCATION

Page-
Figure

Ignition Switch	Attached to steering column	
	Refer to Component Testing Page 145 for additional testing details.	
Washer Pump	In washer reservoir	
Windshield Wiper/Washer Switch	On LH side of I/P	102-2
	Refer to Component Testing Page 144 for additional testing details.	
Wiper Motor Assembly ...	Attached to center of dash panel	

Refer to the **Location Index** in the back of the manual for connector, ground, diode, and splice descriptions and locations.

3. through section **A** of the wiper switch and the **W** wire to the **Wiper Motor** L terminal;
4. through **Wiper Motor** C terminal to ground.
5. When the **Wiper Motor** reaches the end of its travel, the wiper motor switch moves to PARK position. In this position, power is

removed from the motor, and operation stops.


Refer to section 35-01 of the shop manual.

TROUBLESHOOTING HINTS

CONDITION	POSSIBLE CAUSE	ACTION
<ul style="list-style-type: none"> • Washer Pump doesn't work 	<ul style="list-style-type: none"> • Circuit Breaker In Wiper/Washer Switch is open • Damaged hoses • Defective Pump Motor 	<ul style="list-style-type: none"> • Reset and check for shorts to ground in BK wire • Repair/Replace as required • Replace with known good motor
<ul style="list-style-type: none"> • Wipers don't work 	<ul style="list-style-type: none"> • Circuit Breaker in Wiper/Washer Switch is open • Defective Wiper Motor • Frayed or damaged wires or loose connections 	<ul style="list-style-type: none"> • Reset and check for shorts to ground in BK wire • Replace with known good motor • Repair/Replace as required.

100 INTERVAL WIPER/WASHER

SEE CHARGE/
POWER DISTRIBUTION
PAGE 19, 24



SEE GROUNDS
PAGE 6,7

HOW THE CIRCUIT WORKS

The **Interval Windshield Wiper/Washer** allows the driver to select LO speed, HI speed, or INTerval wipe. In INTerval, the wipes can be spaced one second to fifteen seconds apart.

The **Interval Windshield Wiper/Washer Switch** has a momentary washer switch, a four-position wiper switch, and a variable resistor which sets interval time.

Washer Operation

As long as the washer switch is pressed, current flows directly to the **Washer Pump** motor.

Wiper Operation

When the wiper switch is in the LO position, section **A** of the wiper switch powers the interval timer input so that the electronic switch is pulled closed. Current then flows through the wiper/washer switch, wire **63R**, the diode, the governor relay coil, wire **58W**, and section **B** of the wiper/washer switch to **G502**. The governor relay coil pulls in the governor switch allowing current to flow through the motor.

When the wiper switch is in the HI position, section **C** of the wiper/washer switch powers the motor through the H terminal.

When the wiper switch is placed in the OFF position, the circuit energizing the **Interval Governor** relay coil is broken. Current to the motor then flows through circuit **63**, the RUN contact of the wiper motor switch, and the de-energized **Interval Governor** relay contacts to the L terminal of the motor. After the completion of one wipe, the wiper motor switch returns to the PARK position. This removes power and the wiper motor stops.

COMPONENT LOCATION

Page-
Figure

Interval Governor	Lower reinforcement of I/P to left side of cowl	102-1
Interval Windshield Wiper/ Washer Switch	On LH side of I/P	102-2
Refer to Component Testing Page 144 for additional testing details.		
Washer Pump	In washer reservoir	—
Wiper Motor Assembly ...	Attached to center of dash panel	—

Refer to the **Location Index** in the back of the manual for connector, ground, diode, and splice descriptions and locations.

Interval Wiper Operation

During interval operation, the wipers make single wipes at low speed separated by a variable length pause.

When first switched to INT position, section **A** of the wiper switch activates the interval timer. The interval timer momentarily closes the electronic switch, energizing the governor relay. Current flows to the wiper motor L terminal through the energized contacts of the governor relay. Ground is connected to terminal C of the wiper motor.

As the wiper motor turns, the wiper motor switch changes from the grounded PARK position to the hot RUN position. Current now flows through the **R** wire, the RUN contact of the wiper motor switch and resets the interval timer, which opens the electronic switch. The current path continues through the de-energized governor relay contact to the L terminal of the wiper motor. Wiping continues to the completion of one wipe. The wiper motor

switch returns to the PARK position contact, power is removed and the wiper motor stops. After a pause (controlled by a variable resistor) the interval timer pulls in the governor relay to start another wipe.

When parking is complete, the wiper motor is braked to a stop by grounding the L and C terminals through the wiper motor switch. Braking takes place when the wiper motor switch moves to the PARK position. The wiper motor L terminal is grounded through the PARK contact of the wiper motor switch and the de-energized contact of the governor relay.

Refer to section 35-01 of the shop manual.

102 INTERVAL WIPER/WASHER

TROUBLESHOOTING HINTS

CONDITION	POSSIBLE CAUSE	ACTION
<ul style="list-style-type: none"> No Wipers in interval position 	<ul style="list-style-type: none"> Variable resistor of Wiper Switch is defective Defective Interval Governor 	<ul style="list-style-type: none"> Repair/Replace as required Replace as required with known good governor
<ul style="list-style-type: none"> Interval time is too long 	<ul style="list-style-type: none"> Defective Interval Governor 	<ul style="list-style-type: none"> Replace as required with known good governor
<ul style="list-style-type: none"> Wipers operate in HI speed only 	<ul style="list-style-type: none"> Poor ground connection on BK wire from Wiper Switch Defective Interval Governor 	<ul style="list-style-type: none"> Clean/Tighten connections and check for opens in BK wire Replace as required with known good governor




Figure 1 – Behind LH Corner of I/P





Figure 2 — Main Light Switch



HOW THE CIRCUIT WORKS

With the **Ignition Switch** in ACCY or RUN, voltage is applied through **Circuit Breaker 14** to the **Master Window Control** and the **RH Window Control**. These controls control voltage through the **Window Motors** in one direction for UP, and they reverse the current direction for DN.

In the "at rest" position, all switches ground both wires of each motor.

To raise the window, voltage is applied through the UP side of the switch, through the motor, through the motor circuit breaker, and through the DN side of the switch to ground.

To lower the window, voltage is applied in the opposite direction.

Refer to section 42-01 of the shop manual.

COMPONENT LOCATION

Page-
Figure

Master Window Control ..	In LH door	105-2
RH Window Control	In RH door	105-3
Window Motors	In respective doors	105-1

Refer to the **Location Index** in the back of the manual for connector, ground, diode and splice descriptions and locations.

TROUBLESHOOTING HINTS

CONDITION	POSSIBLE CAUSE	ACTION
<ul style="list-style-type: none"> No Windows operate 	<ul style="list-style-type: none"> No voltage at LB/BK wire of Window Control Poor ground continuity at BK wires from Master Window Control Frayed or damaged wires or loose connections 	<ul style="list-style-type: none"> Check Circuit Breaker 14 and wiring Clean/Tighten connections and check wires for opens Repair/Replace as required
<ul style="list-style-type: none"> One Motor doesn't work 	<ul style="list-style-type: none"> If passenger's window motor doesn't work, no voltage at Y/BK or R/BK wires of RH Front Window Control Defective Motor 	<ul style="list-style-type: none"> Repair opens in wires Repair/Replace motor as required




Figure 1 – RH Door




Figure 2 – LH Door




Figure 3 – RH Door

HOW THE CIRCUIT WORKS

TAILGATE POWER WINDOW

With **Ignition Switch** in ACCY or RUN, voltage is applied through **Fuse 14** to the **Driver's Tailgate Window Switch** on the instrument panel to run the **Tailgate Power Window Motor**.

The **Tailgate Window Limit Switch** does not allow the motor to run with the tailgate open.

Voltage is applied at all times through **Fuse 12** to the **Key Switch** in the tailgate to run the motor.

Either switch assembly sends current through the motor in one direction for UP, and the opposite direction for DN.

In OFF position, both motor wires are grounded through separate switches.

When the DN switch is pushed, power flows to the DN motor lead. The UP lead acts as ground.

When the UP switch is pushed, power flows to the UP motor lead. The DN lead acts as ground.

Refer to section 42-01 of the shop manual.

COMPONENT LOCATION

		Page- Figure
Rear Defrost Control	Under LH corner of I/P	108-2
Driver's Tailgate Window Switch	LH side of I/P	108-2
Fuse Link M	LH fender apron	—
Tailgate Power Window Motor	In center of tailgate	109-3
Tailgate Window Limit Switch	LH latch	—
Key Switch	LH side of tailgate	109-3

Refer to the **Location Index** in the back of the manual for connector, ground, diode, and splice descriptions and locations.

REAR WINDOW DEFROST

With the **Ignition Switch** in RUN, the **Rear Defrost Control** is powered through **Fuse 5**.

Pressing the momentary defrost switch ON closes the contacts of the defrost relay and starts the ten minute (approximate) timing cycle. Current now flows through **Fuel Link M** to the **Rear Window Defrost Grid**. When the defrost switch is released from ON, the solid-state circuitry keeps the defrost relay coil energized.

Pressing the defrost switch OFF drops out the defrost relay. This removes power from the defrost circuit.

If the OFF switch is not pressed, power will remain on until the time delay runs out. Then the coil will drop out and remove power from the defrost circuit.

Refer to section 36-01 of the shop manual.

108 TAILGATE POWER WINDOW/REAR WINDOW DEFROST

TROUBLESHOOTING HINTS — TAILGATE POWER WINDOW

CONDITION	POSSIBLE CAUSE	ACTION
<ul style="list-style-type: none"> Window works from Key Switch but not from Driver's Switch 	<ul style="list-style-type: none"> No voltage at LB/BK wire of Defective Driver's Switch Frayed or damaged wires or loose connections 	<ul style="list-style-type: none"> Check Fuse 14 and wiring Replace with known good switch Repair/Replace as required
<ul style="list-style-type: none"> Window works from Driver's Switch but not from Key Switch 	<ul style="list-style-type: none"> No voltage at BK/W wires of Key Switch Defective Key Switch Frayed or damaged wires or loose connections 	<ul style="list-style-type: none"> Check Fuse 12 and wiring Replace with known good switch Repair/Replace as required

TROUBLESHOOTING HINTS — REAR WINDOW DEFROST

CONDITION	POSSIBLE CAUSE	ACTION
<ul style="list-style-type: none"> Defrost does not operate 	<ul style="list-style-type: none"> No voltage at P/O wire of Defrost Control No voltage at Y wire of Defrost Control No voltage at BR/LB wire of Defrost Grid Defective Defrost Switch Relay 	<ul style="list-style-type: none"> Check Fuse 5 and wiring Check Fuse Link M and wiring Check Rear Defrost Control and wiring Replace with known good Defrost Control




Figure 1 — Rear Window Electric Defrost Control Wiring Installation and Rear Window Regulator Switch Assembly Wiring Installation




Figure 2 — Rear Window Electric Defrost Control and Rear Window Regulator Switch (Rear View)

TAILGATE POWER WINDOW/REAR WINDOW DEFROST 109




Figure 3 - Tailgate (Bronco)




Figure 4 - Rear LH Light Assembly





Figure 5 - At Rear Crossmember

110 POWER DOOR LOCKS



HOW THE CIRCUIT WORKS

Power Door Locks are powered through **Circuit Breaker 12** (hot at all times).

When either **Door Control Switch** is pressed to LOCK, voltage is applied to both **Door Lock Motors**. The motors turn in the direction to lock the locks. When either switch is pressed to UNLOCK, voltage of opposite potential is sent to the **Door Lock Motors**, turning them in the UNLOCK direction. When "at rest," the switches are grounded.

Refer to section 44-01 of the shop manual.

COMPONENT LOCATION

Page-
Figure

Door Lock Motors	In respective door	105-1
Door Lock Switches	In respective doors	105-2,3

Refer to the **Location Index** in the back of the manual for connector, ground, diode and splice descriptions and locations.

TROUBLESHOOTING HINTS

CONDITION	POSSIBLE CAUSE	ACTION
<ul style="list-style-type: none"> • No Locks work 	<ul style="list-style-type: none"> • No voltage at BK/W wire of C1962 	<ul style="list-style-type: none"> • Check Circuit Breaker 12 and wiring
<ul style="list-style-type: none"> • One door does not lock (unlock) 	<ul style="list-style-type: none"> • Defective Motor • Frayed or damaged wiring or loose connections 	<ul style="list-style-type: none"> • Repair/Replace with known good motor • Repair/Replace as required
<ul style="list-style-type: none"> • One Switch does not work 	<ul style="list-style-type: none"> • Frayed or damaged wiring or loose connections • Defective Switch 	<ul style="list-style-type: none"> • Repair/Replace as required • Replace with known good switch

112 POWER DOOR LOCKS








Figure 1 – RH Cowl Center Access Hole



FRONT AND REAR SPEAKERS FRONT SPEAKERS ONLY



HOW THE CIRCUIT WORKS

With the **Ignition Switch** in ACCY or RUN, voltage is applied through **Fuse 11** to operate the radio. Circuit number 54 powers the Radio Memory. Circuit number 484 powers the LCD Radio Lighting.

Stereo Radio

The AM/FM/MPX **Stereo Radio** has two **Front Door Speakers** and two optional **Rear Speakers** (Bronco only).

Refer to section 35-01 of the shop manual.

COMPONENT LOCATION

Main Light Switch	Lower I/P, left of steering column	Page- Figure
	102-2	
Refer to Component Testing Page 141 for additional testing details.		
Radio	Center of I/P	—

Refer to the **Location Index** in the back of the manual for connector, ground, diode and splice descriptions and locations.

TROUBLESHOOTING HINTS

CONDITION	POSSIBLE CAUSE	ACTION
<ul style="list-style-type: none"> • Radio does not work 	<ul style="list-style-type: none"> • No voltage at Y/BK wire of Radio 	<ul style="list-style-type: none"> • Check Fuse 11 and wiring
<ul style="list-style-type: none"> • Radio Memory, Display and Clock do not work 	<ul style="list-style-type: none"> • No voltage at LG/Y wire of Radio 	<ul style="list-style-type: none"> • Check Fuse 8 and wiring




Figure 1 – RH Lower Shroud Access Hole




Figure 2 - Speaker Assembly R.H. Side




Figure 3 - Speaker Assembly L.H. Side




Figure 4 - Rear Sear Speaker R.H. Side (Bronco)




Figure 5 - Rear Seat Speaker L.H. Side (Bronco)






Figure 6 - Rear Seat Speaker Installation (Bronco)

HOT AT ALL TIMES



HOT AT ALL TIMES



118 TRAILER OPTION

HOW THE CIRCUIT WORKS

Power for the **Camper** or **Trailer** circuits is provided through fuse links at the **Starter Relay**. Trailer exterior lamps and accessories are powered through **Fuse Link G**. Trailer brakes and brake lamps are powered through **Fuse Link F**.

Refer to section 32-01 of the shop manual.

COMPONENT LOCATION



Page-
Figure

Fuse Link F, G At starter relay


Refer to the **Location Index** in the back of the manual for connector, ground, diode and splice descriptions and locations.

TROUBLESHOOTING HINTS

CONDITION	POSSIBLE CAUSE	ACTION
<ul style="list-style-type: none"> Trailer Lamps don't light 	<ul style="list-style-type: none"> No voltage at R or Y wires of circuit Poor in-line circuit connections 	<ul style="list-style-type: none"> Check Fuse Links F and G and wiring Clean/Tighten and/or repair open in wiring




"CUT" HOSES REFERENCED BETWEEN PAGES
ARROW SHOWS VACUUM FLOW FROM MANIFOLD FITTING TO COMPONENT



NOTE
Other vacuum symbols used on vacuum system diagrams are fully explained on those pages.


VACUUM MOTOR OPERATIONS

SINGLE DIAPHRAGM MOTOR




Vacuum motors operate like electrical solenoids, mechanically pushing or pulling a shaft between two fixed positions. When vacuum is applied, the shaft is pulled in. When no vacuum is applied, the shaft is pushed all the way out by a spring.

SERVO MOTOR



Some vacuum motors such as the **Servo Motor** in the **Speed Control** can position the actuating arm at any position between fully extended and fully retracted. The **Servo** is operated by a control valve that applies varying amounts of vacuum to the motor. The higher the vacuum level, the greater retraction of the motor arm. **Servo Motors** work exactly the same as the two-position motors; the only difference is in the way the vacuum is applied. **Servo Motors** are generally larger and provide a calibrated control.

DOUBLE DIAPHRAGM MOTOR



A double diagram motor has three positions and is really two motors in one housing. When the top port gets vacuum, the shaft pulls half-way in. When both ports get vacuum, the shaft pulls all the way in.

120 VACUUM DISTRIBUTION




Figure 1 - 4.9L




Figure 2 - 5.0L




Figure 3 - 7.5L

TROUBLESHOOTING STEPS

These six steps present an orderly method of troubleshooting:

Step 1. Verify the problem.

- Operate the complete system and see all symptoms for yourself in order to:
 - check the accuracy and completeness of the customer's complaint.
 - learn more that might give a clue to the nature and location of the problem.

Step 2. Narrow the problem.

- Using the EVTMM, narrow down the possible causes and locations of the problem in order to more quickly find the exact cause.

Step 3. Test the cause.

- Use test procedures to find the specific cause of the symptoms.

Step 4. Verify the cause.

- Confirm the fact that you have found the correct cause through operating the parts of the circuit you think are good.

Step 5. Make the repair.

- Repair or replace the faulty component.

Step 6. Verify the repair.

- Operate the system as in Step 1 and check that your repair has removed all symptoms, and also has not caused any new symptoms.

TROUBLESHOOTING TESTS

NOTE

Vacuum system problems fall into three groups:

1. *Leaks* in hoses, connectors, or motor diaphragms.
2. *Pinched Lines* or *Clogged Valves*.
3. *Faulty mechanical operation* of parts driven by vacuum motors.

Vacuum Supply Test




Figure 1 — System Supply Test

1. Connect **Vacuum Tester** to system side of **Check Valve** (Figure 1).
2. Start engine. Gauge should show approximately 15" of vacuum.
3. Turn off engine. Watch gauge.
 - If vacuum holds, supply OK.
 - If vacuum fails, replace **Check Valve** or **Tank**.

Leak Test

1. Connect **Vacuum Gauge** and **Vacuum Pump** (Figure 3) to system hose in place of tank.
2. Open valve and start pump. Operate controls in all modes.
3. Listen for hiss, watch gauge.

NOTE

Hissing is normal at **Function Control** when changing modes.

If system hisses or loses vacuum, find system leak as follows:

1. Turn on **Vacuum Pump** and check for vacuum build-up.

2. Stop pump, vacuum should drop due to leak.
3. Clamp supply hoses with needle-nose pliers one at a time until vacuum stops dropping (Figure 3).
4. Check vacuum schematic to find components in that line.
5. Clamp hoses through circuit to find leak.

Component Test

1. Connect **Vacuum Tester** (Figure 2) to component.
2. Pump **Vacuum Tester** and check that component operates correctly and vacuum holds.
3. Replace component if vacuum doesn't hold.




Figure 2 — Vacuum Tester





Figure 3 — Testing For Leak In Typical Vacuum System

122 SPEED CONTROL



124 SPEED CONTROL

HOW THE CIRCUIT WORKS

The **Speed Control Amplifier** controls vacuum to the **Speed Control Servo** motor through the modulating valve. The servo motor moves the throttle through the **Actuator** (cable or bead chain).

To operate the **Speed Control System**, the engine must be running and the car speed faster than 30 mph. The system is turned on by pressing the ON switch of the **Speed Control Switch**.

Pressing and releasing SET/ACCEL or COAST sends a command to hold the present speed. This speed is now the *set speed*. The **Speed Sensor** (in the transmission) sends signals to the **Speed Control Amplifier**. These signals tell the amplifier to increase or decrease the vacuum at the servo motor to keep the truck at the *set speed*.

Pressing and holding SET/ACCEL speeds the truck up. The truck speed increases as long as SET/ACCEL is depressed. Releasing SET/ACCEL gives the system a new *set speed* to maintain. Truck speed may also be increased by depressing the accelerator until the higher speed is reached, then pressing and releasing SET/ACCEL.

Pressing and holding COAST slows the truck down. The truck speed decreases as long as COAST is depressed. Releasing COAST gives the system a new *set speed* to maintain.

COMPONENT LOCATION

Hazard Flasher	On back of fuse panel	—
Clutch Switch	Attached to bracket at top of clutch pedal	—
Horn Switch	Mounted in steering wheel hub assembly	—
Speed Control Amplifier ..	Behind I/P at RH side of steering column	97-2
Speed Control Servo	On LH inner fender next to master brake cylinder	—
Speed Control Switch	Mounted in steering wheel hub assembly	—
Speed Sensor	On transmission	—
Stoplamp Switch	Mounted to bracket at top of brake pedal	—

Page-
Figure

Refer to the **Location Index** in the back of the manual for connector, ground, diode and splice descriptions and locations.

Pressing OFF turns the system off (grounds **LB/BK** wire). The system is also turned off when the brake pedal is depressed (power through **LG/R** and **LG** wire) or the **Ignition Switch** is turned OFF. The **Vacuum Dump Valve** also operates when the brake pedal is depressed. This is a backup device to turn off the system. In trucks with manual transmission, the **Clutch Switch** opens when the clutch pedal is depressed and turns off the system.

When the system has been deactivated by depressing the brake or clutch pedal, the last *set speed* may be resumed by pressing

RESUME. This feature will not work if OFF has been depressed or if truck speed is below 30 mph.

Refer to section 37-01 of the shop manual.

TROUBLESHOOTING HINTS

CONDITION	POSSIBLE CAUSE	ACTION
<ul style="list-style-type: none"> Speed Control does not operate 	<ul style="list-style-type: none"> No voltage at W/P wire of Speed Control Amplifier Poor ground connection at BK wire of Speed Control Amplifier Open wires and/or damaged hoses Actuator cable has more than 1/8 inch free play Speed Control Servo binding Throttle linkage binding 	<ul style="list-style-type: none"> Check Fuse 6 and wiring Clean/Tighten connection and check for open in wiring Repair/Replace as required Adjust as required Repair as required Repair as required





Figure 1 - Speed Control Servo



HOW THE CIRCUIT WORKS

With the **Ignition Switch** in RUN, the **Heater Function Selector Switch** in a position other than OFF, and the **Blower Switch** in LO, MED 1, MED 2, or HI, voltage is applied through **Fuse 9**, the **Blower Motor**, the **Blower Resistors** and the **Blower Switch** to G701.

In LO, MED 1, or MED 2, voltage is applied through one, two or all **Blower Resistors**. In HI, voltage is applied directly from the **Blower Motor** through the switch to ground.

Refer to section 36-01 of the shop manual.

COMPONENT LOCATION

Page-
Figure


Blower Motor	Mounted to heater housing at RH side of dash panel in engine compartment	
Blower Resistors	Mounted to heater housing next to blower motor in engine compartment	131-1
Blower Switch	At center of I/P	—
Refer to Component Testing Page 147 for additional testing details.		
Heater Function Selector Switch	At center of I/P	—
Refer to Component Testing Page 146 for additional testing details.		


Refer to the **Location Index** in the back of the manual for connector, ground, diode and splice descriptions and locations.

TROUBLESHOOTING HINTS

CONDITION	POSSIBLE CAUSE	ACTION
<ul style="list-style-type: none"> • Blower does not work 	<ul style="list-style-type: none"> • No voltage at Blower Motor • Malfunctioning Heater Function Selector Switch • Poor continuity to ground from BK wire • Malfunctioning Blower Motor • Open Blower Resistors • Malfunctioning Blower Switch 	<ul style="list-style-type: none"> • Check Fuse 9 and wiring • Check continuity through switch. If poor continuity, replace switch • Clean/Tighten connection and check wiring for opens • Replace with known good motor • Replace as required • Replace with known good switch

128 A/C HEATER (VACUUM)





HOW THE CIRCUIT WORKS

The A/C-Heater System is controlled by an **A/C-Heater Function Selector Switch** and **Vacuum Valve**, a **Temperature Control Lever Assembly** and a **Blower Switch** located in the instrument panel assembly. The system is also comprised of a **Blower Motor** and housing assembly, a plenum assembly and air distribution ducts, an evaporator assembly and a condenser and compressor.

The **Function Selector Switch** and **Vacuum Valve** operate together to control system vacuum and electrical operation. **Vacuum Motors** operate the various air control doors to direct air flow. The **Function Selector Switch** also applies voltage to the **Blower Motor** and **A/C Clutch Field Coil** circuits. The **Blower Motor** is designed for the ground side switching method of controlling blower operation.

The **Temperature Control Lever** moves a control cable connected to the **Temperature Blend Door** which directs air through or around the **Heater Core**.

The A/C-Heater System also contains a **Clutch Cycling Pressure Switch**. This Switch controls the cycling of the **A/C Clutch Field Coil** to prevent the evaporator from freezing and blocking air flow.

Lever Position and Operation

OFF - Vacuum is applied to the **Outside-Recirculate Door Vacuum Motor**, closing that door to outside air. The **Panel Door** closes the instrument panel outlets. The **Floor-Defrost Door** opens the defroster outlets. The **Blower** does not operate and no air passes through the system.

A/C MAX - The **Outside-Recirculate Door** closes to outside air. The **Panel Door** sends air

COMPONENT LOCATION

Page-
Figure

A/C-Heater Function		
Selector Switch	In center of I/P	—
Refer to Component Testing Page 146 for additional testing details.		
A/C Clutch Field Coil	Part of Compressor	131-2
Blower Motor	Mounted to evaporator at RH side of dash panel in engine compartment	—
Blower Switch		
	At center of I/P	—
Refer to Component Testing Page 147 for additional testing details.		
Blower Resistors	Mounted to evaporator next to blower	131-1
Clutch Cycling Pressure Switch		
	RH side of dash panel on accumulator	—

Refer to the **Location Index** in the back of the manual for connector, ground, diode and splice descriptions and locations.

to the instrument panel outlets (vacuum on motor). With the **Temperature Control Lever** in Cool position, the **Temperature Blend Door** prevents air flow through the **Heater Core**.

A/C NORM - Outside air comes through the **Outside-Recirculate Door**. The **Panel Door** sends air to the instrument panel outlets (vacuum on motor). The **Temperature Blend Door** controls the air through the **Heater Core**.

VENT - Air flow is the same as in A/C NORM. The compressor is OFF.

FLOOR - Outside air is passed through or around the **Heater Core** as controlled by the **Temperature Control Lever**. The **Panel Door** is closed and air is sent to the floor outlets (vacuum at 7A and 7B of the **Floor-Defrost Door Vacuum Motor**). The compressor is OFF.

MIX - The **Outside-Recirculate Door** lets in outside air (no vacuum at motor). Vacuum is applied to port 7A of the **Floor-Defrost Door**. The door moves to mid position and air is split between the floor and defrost outlets. The **Panel Door** closes and the A/C compressor operates to dehumidify the air.

DEFROST - With no vacuum at any Vacuum Motor, air passes through the outlets. The compressor operates to dehumidify the air.

Refer to section 36-01 of the shop manual.

TROUBLESHOOTING HINTS

CONDITION	POSSIBLE CAUSE	ACTION
<ul style="list-style-type: none"> Blower does not work 	<ul style="list-style-type: none"> No voltage at Blower Motor Malfunctioning A/C-Heater Function Selector Switch Poor continuity to ground from BK wire of Blower Switch Malfunctioning Blower Motor Open Blower Resistors Malfunctioning Blower Switch 	<ul style="list-style-type: none"> Check Fuse 9 and wiring Check continuity through switch. If poor continuity, replace switch Clean/Tighten connection and check wiring for opens Replace with known good motor Replace as required Replace with known good switch
<ul style="list-style-type: none"> Compressor Clutch does not work 	<ul style="list-style-type: none"> No voltage at BK/Y wire of A/C Clutch Field Coil with ON Open in A/C Clutch Field Coil No continuity of BK wire of A/C Clutch Field Coil to ground Lack of R-12 refrigerant 	<ul style="list-style-type: none"> Check Fuse 9 and wiring Replace with known good coil Check for open in BK wire Recharge as required
<ul style="list-style-type: none"> Hissing: No recirculating air 	<ul style="list-style-type: none"> Vacuum line leak Malfunctioning Vacuum Motor 	<ul style="list-style-type: none"> Replace as required Replace with known good motor
<ul style="list-style-type: none"> No cooling or not enough cooling 	<ul style="list-style-type: none"> Compressor Drive Belt is loose Temperature Control Cable is out of adjustment 	<ul style="list-style-type: none"> Tighten/Replace as required Adjust as required




Figure 1 — Blower Resistor Assembly




Figure 2 — Air Conditioning Compressor Field Coil

132 A/C-HEATER (ELECTRICAL)




Figure 3 — 5.0L & 5.8L Engine




Figure 4 — 7.3L Diesel Engine




Figure 1 — LH View 4.9L EFI Engine




Figure 2 — RH View 4.9L EFI Engine




Figure 3 — RH View 5.0L Engine

136 ENGINE VIEWS — 5.0L & 5.8L EFI




Figure 4 — LH View 5.0L & 5.8L Engine




Figure 5 — LH View 7.3L with Manual Transmission

138 ENGINE VIEWS - 7.3L DIESEL




Figure 6 — LH View 7.3L with E40D Transmission




Figure 7 — RH View 7.3L Diesel

140 ENGINE VIEWS - 7.5L EFI





Figure 8 — RH View 7.5L Engine

INTRODUCTION

Component testing procedures are provided to prove that a component is good or bad.

Testing information for each component includes a schematic, component terminal locations and step-by-step test procedures. Component terminals are identified:

- 1) by the circuit number of the wires that connect to that terminal;
- 2) by the wire insulation color
- 3) by letters or numbers which may be marked on the component.




The component connector **MUST BE REMOVED** before testing. To test a single circuit within the component, select that circuit under the column **TO TEST**. If you wish to test the complete component, perform all tests.

Connect the tester to the terminals shown in the second column and operate the component as shown in the third column.

MAIN LIGHT SWITCH


SCHEMATIC



COMPONENT TESTING PROCEDURE

TO TEST	Connect Self Powered Test Light or Ohmmeter to Terminals	Move Switch to These Positions	A Good Switch Will Indicate
Headlamp Circuit	38 BK/O (B) and 15 R/Y (H)	Off Park Head	Open Circuit Open Circuit Closed Circuit
Park Lamp Circuit	195 T/W (A) and 14 BR (R)	Off Park Head	Open Circuit Closed Circuit Closed Circuit
Dome Light Circuit	54 LG/Y (D1) and 55 BK/PK (D2)	Fully Counter-Clockwise (In Detent) Clockwise (Any Amount Out of Detent)	Closed Circuit Open Circuit
Panel Light Dimmer Circuit	14 BR (R) and 19 LB/R (I)	Rotate Knob Clockwise	Ohmmeter Will Indicate Increasing Resistance
Ignition On, Lamps Off Circuit	137 Y/BK (IGN) and 484 O/BK (DN)	Off Park Head	Closed Circuit Open Circuit Open Circuit
Cluster Dimmer Circuit	19 LB/R (I) and 484 O/BK (DN)	Off Park Head	Open Circuit Closed Circuit Closed Circuit

TERMINAL LOCATIONS ON SWITCH




142 COMPONENT TESTING: IGNITION SWITCH (WITH SWITCH INSTALLED)

COMPONENT TESTING PROCEDURE

TO TEST	Connect Self Powered Test Light or Ohmmeter to Terminals	Move Switch to These Positions	A Good Switch Will Indicate
Internal Switch Connections (perform these tests first)	37 Y (BATT) and 37 Y (BATT)	Accy, Lock, Off, Run, Start	Closed Circuit in all five positions
Starter Relay Circuit	37 Y (BATT) (either terminal) and 32 R/L B (ST)	Accy, Lock, Off, Run, Start	Closed Circuit in Start position only
A/C, Heater Circuit, Turn/Stoplamps, Backup Lamps	37 Y (BATT) (either terminal) and 687 GY/Y (A2) (either terminal)	Accy, Lock, Off, Run, Start	Closed Circuit in Run position only


TERMINAL LOCATIONS



COMPONENT TESTING PROCEDURE

TO TEST	Connect Self Powered Test Light or Ohmmeter to Terminals	Move Switch to These Positions	A Good Switch Will Indicate
Ignition Circuit	37 Y (BATT) (either terminal) and 16 R/LG	Accy, Lock, Off, Run, Start	Closed Circuit in Run.
	37 Y (BATT) (either terminal) and 262 BR/PK (I2)	Accy, Lock, Off, Run, Start	Closed Circuit in Start position only
"Accy" Circuit	37 Y (BATT) (either terminal) and 297 BK/LG (A1)	Accy, Lock, Off, Run, Start	Closed Circuit in Run and Accy position only
Bulb-Test Circuit	41 BK/LB (P2) and Ignition Switch Case	Accy, Lock, Off, Run, Start	Closed Circuit in Start position only
	977 P/W (P1) and Ignition Switch Case	Accy, Lock, Off, Run, Start	Closed Circuit in Start position only

SCHEMATIC



COMPONENT TESTING: TURN/HAZARD SWITCH 143


COMPONENT TESTING PROCEDURE

TO TEST	Connect Self Powered Test Light or Ohmmeter to Terminals	Move Switch to These Positions	A Good Switch Will Indicate
Horn Switch Circuit	460 Y/LB and 1 DB	Depress Horn Switch (If removed from truck, jumper brush contacts)	Closed Circuit
LH Rear Turn Circuit	44 LB and 9 LG/O	Turn Switch to Turn Left and Hazard Switch to Normal	Closed Circuit
LH Front Turn Circuit	44 LB and 3 LG/W	Turn Left	Closed Circuit
RH Rear Turn Circuit	44 LB and 5 O/LB	Turn Right	Closed Circuit
RH Front Turn Circuit	44 LB and 2 W/LB	Turn Right	Closed Circuit


COMPONENT TESTING PROCEDURE

TO TEST	Connect Self Powered Test Light or Ohmmeter to Terminals	Move Switch to These Positions	A Good Switch Will Indicate
Hazard Switch Circuit	385 W/R and 511 LG	Hazard	Closed Circuit
	385 W/R and 2 W/LB	Hazard	Closed Circuit
	385 W/R and 3 LG/W	Hazard	Closed Circuit
Stoplamp Feed-Through Circuit	511 LG and 9 LG/O	Turn Switch to center (No Turn) position or Turn Right	Closed Circuit
	511 LG and 5 O/LB	Turn Switch to center (No Turn) position or Turn Left	Closed Circuit

SCHEMATIC




TERMINAL LOCATIONS



144 COMPONENT TESTING: WINDSHIELD WIPER/WASHER SWITCH


TERMINAL LOCATIONS ON SWITCH




COMPONENT TESTING PROCEDURE

TO TEST	Connect Self Powered Test Light or Ohmmeter to Terminals	Move Switch to These Positions	A Good Switch Will Indicate
Washer Switch Circuit	941 BK/W (W1) and 63 R (B)	Push knob	Closed Circuit
		Release knob	Open Circuit
Wiper Switch Circuit	63 R (B) and 58 W (C)	Off	Open Circuit
		Lo	Closed Circuit
		Hi	Open Circuit
Wiper Switch Circuit	63 R (B) and 56 DB/O (E)	Off	Open Circuit
		Lo	Open Circuit
		Hi	Closed Circuit
Wiper Switch Circuit	58 W (C) and 28 BK/PK (D)	Off	Closed Circuit
		Lo	Open Circuit
		Hi	Open Circuit
Circuit Breaker	297 BK/LG (A) and 63 R (B)	All positions	Closed Circuit

SCHEMATIC




TERMINAL LOCATIONS ON SWITCH



COMPONENT TESTING PROCEDURE

TO TEST	Connect Self Powered Test Light or Ohmmeter to Terminals	Move Switch to These Positions	A Good Switch Will Indicate
Wiper Switch Circuit	57 BK (F) and 57A BK (D)	Off All other positions	Open Circuit Closed Circuit
	63 R (B) and 56 DB/O (C)	Hi All other positions	Closed Circuit Open Circuit
	28 BK/PK (E) and 57 BK (F)	Off Rotate Control Into Position (as Viewed from Connector Side). All other positions	Open Circuit Ohmmeter will indicate smoothly increasing resistance from 200-1000 ohms minimum to 5600-8400 ohms maximum Closed Circuit


SCHEMATIC



146 COMPONENT TESTING: A/C HEATER FUNCTION SELECTOR SWITCH

COMPONENT TESTING PROCEDURE


TERMINAL LOCATIONS




TO TEST	Connect Self Powered Test Light or Ohmmeter to Terminals	Move Switch to These Positions	A Good Switch Will Indicate
A/C Clutch Circuit	182 BR/W and 348 LG/P	Off A/C Max A/C Norm Vent Floor Mix Defrost	Open Circuit Closed Circuit Closed Circuit Open Circuit Open Circuit Closed Circuit Closed Circuit
Blower Motor Circuit	*182 BR/W and 181 BR/O	Off All other positions	Open Circuit Closed Circuit

NOTE: HEATER ONLY USES BLOWER MOTOR CIRCUIT ONLY.


SCHEMATIC A/C HEATER




SCHEMATIC - HEATER ONLY



TERMINAL LOCATIONS



SCHEMATIC



COMPONENT TESTING PROCEDURE

TO TEST	Connect Self Powered Test Light or Ohmmeter to Terminals	Move Switch to These Positions	A Good Switch Will Indicate
LO	57 BK (2)	Lo	Open Circuit
Medium-Low Speed (M1)	57 BK (2) and 752 Y/R (5)	Lo Medium-1 Medium-2 Hi	Open Circuit Closed Circuit Open Circuit Open Circuit
Medium-High Speed (M2)	57 BK (2) and 754 LG/W (4)	Lo Medium-1 Medium-2 Hi	Open Circuit Open Circuit Closed Circuit Open Circuit
Hi Speed	57 BK (2) and 261 O/BK (1)	Lo Medium-1 Medium-2 Hi	Open Circuit Open Circuit Open Circuit Closed Circuit

148 LOCATION INDEX

CONNECTOR LOCATION

		Page-Figure	Color	Terminals
C100	Through dash at LH side	—		53
C103	Near HEGO sensor	—	BK	4
C104	At battery ground pigtail	—		4
C107	At license lamps	60-2	BR	1
C108	Engine compartment LH side	—	BK	4
C109	RH side #6 crossmember	60-3	GY	4
C110	LH fender apron	—	GY	8
C111	Behind I/P LH end (test)	—	BK	1
C112	LH fender apron	—	BR	8
C113	LH fender apron	—	N	8
C114	LH fender apron	—	BK	8
C115	On rear of engine	—	BK	8
C116	LH fender apron	—	BK	8
C117	At LH front side body marker lamp	61-8	BK	4
C118	LH fender apron	—	BK	8
C119	On dash panel	—	GY	4
C122	RH side of rear cross support	60-3	GY	4
C123	LH side of frame at rear crossmember	109-5	BK	4
C126	LH side of rear crossmember	60-2		2
C129	At RH fender apron (diesel only)	35-1	GY	8
C132	LH fender apron	—	BK	8
C133	LH fender apron/#5 crossmember on dual tank	—	BK	4
C134	LH fender apron	—	BK	8
C135	RH inner fender behind headlamp	—	BK	1
C136	At rear left quarter panel	71-2		
C151	Engine compartment	—	BK	4
C157	At A/C clutch switch	—	W	2
C158	At blower switch	—	GY	5
C168	Engine compartment test	—	GY	6
C170	Near ignition module	133-1	BK	2
C171	Engine compartment test	—		1
C174	At proportioning valve, LH frame rail	—	BK	4
C177	Engine compartment LH side	—	GY	4
C182	Engine compartment LH	—	GY	4
C183	Engine compartment LH	—	BR	2
C185	At alternator	135-3		3
C186	At alternator	—		3
C187	At alternator regulator	139-7	W	4
C188	At alternator	—		2
C190	At clutch lockout switch	—	GY	2
C197	LH side of rear cross support	—	GY	8
C202	Lower hole of LH quarter panel	71-2	GY	4
C202A	Lower hole of LH quarter panel	70-1	GY	4
C203	Lower hole of LH quarter panel	—	GY	4
C208A	At instrument cluster	—		14

CONNECTOR LOCATION

		Page-Figure	Color	Terminals
C208B	At instrument cluster	—		14
C233	Near alternator	—	GY	1
C240	At ignition key, seat belt warning buzzer	—		7
C244	Behind center of I/P	—	BK	8
C248	Engine compartment near starter relay	—	GY/BK	4
C260	Near RH battery	—	BK	1
C270	At wiper motor	—		3
C271	At wiper motor	—		3
C276	At automatic transmission	—		5
C280	Engine compartment near starter relay	—		6
C284	At 4x4 switch	—	BK	2
C285	LH fender apron near power brake booster	—	GY	4
C285A	LH fender apron near power brake booster	—	BR	4
C285B	At speed sensor	—	BK	2
C289	RH cowl	—	BK	4
C290	RH cowl	—	GY	4
C292	At blower motor	—		2
C293	At blower resistor	—	W	4
C300	Inline fuel pump	—	BK	2
C305	LH side of steering column	—	GY	11
C305A	LH side of steering column	—	GY	11
C305B	LH side of steering column	—	GY	11
C321	LH fender apron near ignition module	—	BK	3
C322	At distributor	—	BK	3
C323	At ignition module	—	BK	4
C333	Behind center of I/P at radio	—		8
C343	LH fender apron near ignition module	—	BK	8
C344	LH fender apron near ignition module	—	BK	8
C353	Rear LH side of frame at rear crossmember	60-4	Y	1
C354	At LH rear park & turn lamp	60-4	BK	2
C355	At RH rear park & turn lamp	60-4	BK	2
C356	At RH backup lamp	60-4	Y	1
C357	At LH backup lamp	60-4	Y	1
C358	Behind center of I/P	—	GY	2
C366	Behind I/P near fuse panel	—	GY	3
C366A	Behind I/P near fuse panel	—	GY	3
C366B	Behind I/P near fuse panel	—	GY	3
C370	Transmission extension housing	—	GY	4
C380	Engine compartment LH side	—		2
C385	Near alternator/regulator	—	BK	1

CONNECTOR LOCATION

		Page- Figure	Color	Terminals
C386	Near RH battery	—		1
C406	LH cowl under I/P	—	GY	4
C420	Engine compartment LH side	—	BK	4
C425	RH cowl	—	BK	6
C426	RH cowl side	—	GY	2
C427	RH cowl side — electric shift module	—	GY	8
C428	RH cowl side — electric shift module	—	W	10
C429	RH cowl side — electric shift module	—	BR	5
C430	At electric shift transfer case	—	BK	10
C431	At electronic shift switch	—		6
C450	LH side rear support cross	—	BK	2
C522	Behind center of I/P at radio	—		8
C523	Lower LH cowl access hole	—	BR	2
C524	Lower RH cowl access hole	114-1	BR	2
C550	At windshield wiper/washer switch	102-1	BK	10
C650	At RH door lock motor	—	BK	2
C701	At main light switch	—	BK	8
C714	At speed control amplifier	—	GR	8
C717	At speed control amplifier	—	GY	6
C752	LH side of hood at engine compartment lamp	—		1
C753	At speed control servo	—	BR	6
C755	At clutch switch	—	GR	2
C789	LH side of driver's seat on floor pan	79-1	GY	2
C850	Lower LH cowl access hole	—	GY	4
C906	At LH cowl access hole	—		2
C913	At center of rear body markers	60-5		4
C915	Engine compartment LH side	—	BK	2
C918	Near LH side of rear crossmember	60-2	BK	4
C950	At LH rear	61-8		4
C951	Near RH side of rear crossmember	60-6	BR	2
C952	At front of RH side body marker	—	BK	4
C953	At RH rear	61-8	BK	4
C954	In forward part of cab roof	59-1	BK	2
C955	In forward part of cab roof	59-1	BK	2
C956	In forward part of cab roof	59-1	BK	2
C957	At front of cab roof	59-1	BK	2
C958	At front of cab roof	59-1	BK	2
C1101	Behind I/P LH end	—	BK	3
C1102	Behind I/P LH end	—	GY	4
C1105	LH side of frame at rear crossmember	61-9	BK	4
C1110	LH rear engine compartment	61-9	BR	6
C1111	LH rear of frame	—	BR	3

Page-
Figure Color Terminals

C1114	LH rear of frame			4
C1206	At rear crossmember	65-1	GY	3
C1907	Behind LH rear lamp	109-4	BR	3
C1951	Behind LH rear crossmember	109-5	BR	1
C1952	Behind LH rear lamp	109-4	BR	1
C1953	LH cowl center access hole	—	GY	8
C1954	RH cowl center access hole	—	GR	8
C1955	LH cowl area	—		2
C1960	On fuse panel	—	N	1
C1962	At fuse panel	—	BL	2
C1963	LH frame rail	—	BK	2
C1964	Engine compartment LH side	—	BK	4

SPLICE LOCATION

S101	Near inline fuel pump T/O			—
S108	Near tailgate power window switch T/O			—
S109	Near tailgate power window switch T/O			—
S110	Near fuel pump relay T/O			—
S111	Near starter relay T/O			—
S112	Near EEC module T/O			—
S113	Near C115 T/O			—
S114	Near C114 T/O			—
S115	Near manifold pressure sensor T/O			—
S116	Near manifold pressure sensor T/O			—
S117	Near C100 T/O			—
S118	Near EEC module T/O			—
S119	Near E40D T/O			—
S120	Near speed control amplifier T/O			—
S121	Near C112 T/O			—
S123	Near EEC module T/O			—
S124	Near backup lamp switch T/O			—
S125	Near backup lamp switch T/O			—
S126	Near C100 T/O			—
S129	Near E40D Transmission			—
S140	Between S142 and S143			—
S142	Near T/O to no. 4 fuel injector			—
S143	Near T/O to no. 8 fuel injector			—
S150	In ignition coil lead			—
S152	Near LH backup lamp T/O			—
S153	Near license lamp T/O			—
S154	Near front fuel gauge sender T/O			—
S155	Near ERBP valve T/O			—
S156	Near fuel line heater T/O			—
S157	Near LH headlamp T/O			—

150 LOCATION INDEX

SPLICE LOCATION

S158	Near LH glow plugs T/O	—
S159	Near RH glow plugs T/O	—
S160	Near ignition coil T/O	—
S161	Near clutch interlock switch T/O	—
S162	Near heater control switch T/O	—
S163	Near heater control switch T/O	—
S165	In T/O to throttle air bypass solenoid	—
S167	In T/O to map sensor	—
S168	Near T/O to EEC diode	—
S170	Near battery	—
S172	Near T/O to EEC diode	—
S174	Near T/O to EEC power relay	—
S175	Near cooling fan relay T/O	—
S176	Near fuel tank selector valve T/O	—
S177	Near fuel tank selector valve T/O	—
S185	Near radio T/O	—
S190	Near backup lamp T/O	—
S200	Near clutch switch T/O	—
S201	Near T/O to C100	—
S202	Near T/O to fuel pump relay	—
S208	Near main light switch T/O	—
S216	Near steering column connector T/O	—
S217	Near ignition switch T/O	—
S220	Near LH courtesy lamp T/O	—
S221	Near ignition switch T/O	—
S270	Between T/O's to EEC power relay	—
S271	Near T/O to C178 (LH side)	—
S272	Near main light switch T/O	—
S276	Near T/O to C178 (LH side)	—
S277	Near T/O to C178 (RH side)	—
S303	Near main light switch T/O	—
S305	In ignition coil lead	—
S350	Near main light switch T/O	—
S352	Near vehicle speed sensor T/O	—
S353	Near vehicle speed sensor T/O	—
S360	Near LH horn T/O	—
S404	Near clutch switch T/O	—
S410	Behind I/P in cooling fan harness	—
S450	Near license lamp T/O	—
S451	Near license lamp T/O	—
S452	Near rear turn/stoplamp T/O	—
S501	Near RH courtesy lamp T/O	—
S503	Near instrument cluster T/O	—

SPLICE LOCATION

S504	Near instrument cluster T/O	—
S507	Near warning buzzer T/O	—
S508	Near warning buzzer T/O	—
S509	Near anti-lock brake module T/O	—
S510	Near anti-lock brake module T/O	—
S511	Near anti-lock brake module T/O	—
S512	Near fuel tank selector T/O	—
S513	Near fuse panel T/O	—
S515	Near driver's tailgate window switch T/O	—
S517	Near LH courtesy lamp T/O	—
S520	Near warning buzzer T/O	—
S530	Near clutch interlock switch T/O	—
S536	Near windshield wiper motor T/O	—
S538	Engine compartment near air charge sensor T/O	—
S543	Near brake sensor T/O	—
S545	Near LH headlamp T/O	—
S547	Engine compartment near HEGO ground T/O	—
S548	Engine compartment near #5 fuel injector T/O	—
S549	Engine compartment near #3 fuel injector T/O	—
S550	Near brake sensor T/O	—
S551	Engine compartment near #3 fuel injector T/O	—
S552	Engine compartment near throttle air bypass solenoid T/O	—
S554	Near speed sensor T/O	—
S555	Near ignition module T/O	—
S556	Near ignition module T/O	—
S560	Near fuel sedimenter bowl T/O	—
S562	Near A/C clutch T/O	—
S563	Near A/C clutch T/O	—
S567	Near T/O to A/C pressure cycling switch	—
S570	Near fuel tank sender T/O	—
S571	Near fuel tank sender T/O	—
S576	Near LH backup lamp T/O	—
S578	Near LH backup lamp T/O	—
S583	Near T/O to A/C clutch coil	—
S584	Near T/O to A/C clutch coil	—
S590	In LH door near power window switch T/O	—
S603	Near blower motor switch T/O	—
S701	Near blower resistor T/O	—
S801	Near headlamp switch T/O	—
S805	Near cigar lighter T/O	—
S806	Near T/O to windshield wiper switch	—
S807	Near LH headlamp T/O	—
S808	Near RH park lamp T/O	—

SPLICE LOCATION

S811	Near ignition switch T/O	—
S814	Near windshield wiper illumination lamp T/O	—
S815	Near G701 T/O	—
S850	Near main light switch T/O	—
S852	Near LH master window control switch T/O	—
S853	Near LH master window control T/O	—
S854	Front LH door near speaker T/O	—
S858	Near LH master window control T/O	—
S902	Near RH side marker lamp T/O	—
S903	Near fuel gauge sender and pump T/O	—
S904	Near license lamp T/O	—
S1004	Near ignition switch T/O	—
S1103	Near RH courtesy lamp T/O	—
S1108	Near rear marker lamp T/O	—
S1109	Near LH front side marker lamp T/O	—
S1152	Near RH front side marker lamp T/O	—
S1205	Near rear license lamp T/O	—
S1207	Near dome lamp T/O	—
S1208	Near dome lamp T/O	—
S1902	Near tailgate power window switch T/O	—

DIODE LOCATION

D100	150 mm (5.9 in.) from a/c clutch	132-3,4
D101	910 mm (35.9 in.) from cargo lamp	70-1
D200	1117 mm (44 in.) from parking brake switch	—
D201	520 mm (20.5 in.) from ignition switch	—

GROUND LOCATION

G111	RH frame near battery	26-1
G116	Near electronic engine control	—
G117	Near ignition coil	—
G119	Behind I/P near center	—
G155	LH rear of engine	—
G156	Center of dash panel	—
G203	On RH side of engine	21-1, 2

GROUND LOCATION

G208	Near throttle position solenoid	—
G209	Center of dash panel	—
G210	At electronic voltage regulator	—
G211	Near starter motor relay	—
G301	Near underhood lamp	—
G502	Behind LH side of I/P	102-1
G701	Behind I/P at center	—
G703	At brace under steering column	—
G710	LH side of dash panel	—
G711	LH rear of engine	—
G751	At LH side of tailgate	—
G752	In LH door	—
G801	LH inner fender behind headlamp	—
G802	At RH inner fender behind headlamp	—
G803	At fuel sedimenter bowl	—
G804	At lower hole of LH quarter panel	—
G805	At RH inner fender behind headlamp	—
G903	At LH side of crossmember	60-2
G909	At lower LH cowl access hole	—
G1006	Rear LH side of frame at rear crossmember	61-9
G1201	At front LH side of engine	26-1

We Want To Hear From You!

Do you have any suggestions for improving this publication?

FOR EXAMPLE . . .

- Did you find any errors?

If yes; Manual _____ Page _____

- Were any subjects not covered?

If yes; Please describe. _____

- Were any sections confusing or hard to understand?

If yes; Manual _____ Page _____

Please comment: _____

- Could you quickly find what you need? Yes _____ No _____

Suggestion: _____

- Tell us who you are:

Name _____

Address _____

Position _____ Company _____

It would be most helpful if you could enclose a copy of each page, marked with your suggestions.



**WE SUPPORT VOLUNTARY
TECHNICIAN CERTIFICATION**



**Ford Parts and Service Division
Training and Publications Department**

